



Hemico PN	OEM PN	Description	Application
APM129-170001-3	129-170001-3	Lens	HB 1900
APM129-170001-4	129-170001-4	Lens	HB 1900
APM85720093-101	85720093-101	Lens	DHC-8-100/200300/400
APM85720093-102	85720093-102	Lens	DHC-8-100/200300/400
APM85720094-101	85720094-101	Lens	DHC-8-100/200300/400
APM85720094-102	85720094-102	Lens	DHC-8-100/200300/400
HDCSA-240	27-24150-449	Door Cable	Metro SA227
HDCSA-348	27-24150-447	Door Cable	Metro SA227
HDCSA-480	MUV901503-61	Door Cable	HB 400, 400A
HEM100-820018-7	100-820018-7	Bracket Assembly	HB 90,100,200
HEM100-820019-1	100-820019-1	Bolt	HB 90, 99, 100, 200, 300, 1900
HEM101-120108-151	101-120108-151	Gasket	HB 200, 300
HEM101-521033-1	101-521033-1	Washer	HB 200, 300, 1900
HEM101-521034-1	101-521034-1	Washer	HB 200, 300, 1900
HEM101-810009-7	101-810009-7	Spacer	HB 200, 300
HEM101-810024-1	101-810024-1	Bushing	HB 200, 300
HEM101-810024-3	101-810024-3	Bushing	HB 1900
HEM101-810024-5	101-810024-5	Bushing	HB 1900
HEM101-810085-1	101-810085-1	Decal	HB 200, 300, 1900
HEM101-810090-1	101-810090-1	Bolt	HB 99, 200, 1900
HEM101-810093-1	101-810093-1	Bushing	HB 90, 99, 200
HEM101-810136-9	101-810136-9	Down Lock Hook	HB 200, 300
HEM101-810136-10	101-810136-10	Down Lock Hook	HB 200, 300
HEM101-810137-3	101-810137-3	PIN	HB 200, 300
HEM101-810151-1	101-810151-1	Bolt	HB 200, 300
HEM101-810153-9	101-810153-9	Plate	HB 200, 300
HEM101-810177-3	101-810177-3	Bolt	HB 200, 300
HEM101-810182-1	101-810182-1	Bolt	HB 200, 300
HEM101-810182-3	101-810182-3	Bolt	HB 200, 300
HEM101-810200-1	101-810200-1	Idler	HB 200, 300
HEM101-820022-1	101-820022-1	Bushing	HB 200, 300
HEM101-820028-1	101-820028-1	Bushing	HB 90, 99
HEM101-820052-1	101-820052-1	Plate	HB 90, 200, 300
HEM101-820053-1	101-820053-1	Plate	HB 90, 200, 300
HEM105090CRO25-12J	105090CRO25-12J	Washer	HB 90, 99, 100, 200, 300, 1900
HEM105739X-XW1160	105739X-XW1160	Bushing	HB 90, 100, 200, 300
HEM105739X-YR0600	105739X-YR0600	Bushing	HB 99
HEM105739X-YR0875	105739X-YR0875	Bushing	HB 90, 99, 100, 200, 300, 1900
HEM105739X-YR1000	105739X-YR1000	Bushing	HB 200, 300
HEM105740X-YK0563	105740X-YK0563	Bushing	HB 99, 200
HEM105740X-YN0625	105740X-YN0625	Bushing	HB 90, 100, 200, 300, 1900
HEM105740X-YN0677	105740X-YN0677	Bushing	HB 1900
HEM109-00200	109-00200	Wear Pad	HB 90, 99, 100, and 200
HEM109-00201	109-00201	Wear Pad	HB 1900
HEM114-388015-1	114-388015-1	Lower Piston Bearing	HB 1900
HEM114-388016-1	114-388016-1	Bolt	HB 1900
HEM114-580114-1	114-580114-1	Tube Assembly	HB 1900
HEM114-810025-3	114-810025-3	Link	HB 1900
HEM114-810025-4	114-810025-4	Link	HB 1900
HEM114-810028-1	114-810028-1	Rig Plate	HB 1900
HEM114-810038-1	114-810038-1	Bushing	HB 1900
HEM114-810042-1	114-810042-1	Bushing	HB 1900
HEM114-810043-1	114-810043-1	Support Assembly	HB 1900
HEM114-810043-3	114-810043-3	Support	HB 1900
HEM114-810049-3	114-810049-3	Bushing	HB 1900
HEM114-810050-3	114-810050-3	Roller	HB 1900
HEM114-820051-1	114-820051-1	Orifice	HB 1900
HEM114-820058-1	114-820058-1	Bushing	HB 200, 300
HEM114-820069-1	114-820069-1	Bearing Sleeve	HB 90, 99, 200, 300
HEM114-820069-3	114-820069-3	Bearing Sleeve	HB 1900
HEM114-820077-1	114-820077-1	Bracket Assembly	HB 1900
HEM114-820077-3	114-820077-3	Bracket	HB 1900
HEM114-820107-1	114-820107-1	Bolt	HB 1900
HEM114-820113-1	114-820113-1	Bushing	HB 1900
HEM115-380113	115-380113	Lower Piston Bearing	HB 200
HEM115-810064-1	115-810064-1	Bushing	HB 90, 99, 100, 200
HEM115-810065-1	115-810065-1	Washer	HB 90, 99, 100, 200, 300, 1900
HEM115-810065-9	115-810065-9	Washer	HB 1900
HEM115-810066-3	115-810066-3	Bushing	HB 99, 100, 200, 300, 1900
HEM115-810073-1	115-810073-1	Cover	HB 90, 99, 100, 200
HEM118-100000-9	118-100000-9	Washer	HB 200, 300, 1900
HEM128-810002-0001	128-810002-0001	Bolt	HB 400, 400A
HEM128-810035-3	128-810035-3	Bolt	HB 400, 400A
HEM128-810048-1	128-810048-1	Pin	HB 400, 400A
HEM128-820043-1	128-820043-1	Pin	HB 400, 400A
HEM205-00600	205-00600	Drive Key	HB 1900
HEM20-677	20-677	Wear Pin	DHC-8-400

HEM260-813	260-813	Adjuster Housing	DHC-8-100/200/300, ATR-42-300/500
HEM27-51504-001	27-51504-001	Valve Pin	Metro SA227
HEM27-90264-005	27-90264-005	Fork	Metro SA227
HEM27-90282-005	27-90282-005	Shaft	Metro SA227
HEM35-521213-5	35-521213-5	Flap Act. Housing	HB 90, 99, 100, 200, 300
HEM45034-3	45034-3	Shim	HB 400, 400A
HEM45039-3	45039-3	Shim	HB 400, 400A
HEM45224-3	45224-3	Shim	HB 400, 400A
HEM46027-5	46027-5	Adapter	HB 400, 400A
HEM46029-3	46029-3	Washer	HB 400, 400A
HEM46032-3	46032-3	Washer	HB 400, 400A
HEM46034-5	46034-5	Bolt	HB 400, 400A
HEM46043-9	46043-9	Shim	HB 400, 400A
HEM46056-3	46056-3	Bushing	HB 400, 400A
HEM46114-3	46114-3	Bushing	HB 400, 400A
HEM46128-3	46128-3	Nut	HB 400, 400A
HEM50-395	50-395	Identification Plate	DHC-8-400
HEM50-521149	50-521149	Piston Plug	HB 90, 99, 100, 200, 300, 1900
HEM50-521153-3	50-521153-3	Pin	HB 90, 99, 100, 200, 300, 1900
HEM50-521195-10	50-521195-10	Flap Piston	HB 90, 99, 100, 200, 300
HEM50-521203-3	50-521203-3	Flap Act. Housing	HB 90, 99, 100, 200, 300
HEM50-533	50-533	Instruction Plate	DHC-8-400
HEM50-810034	50-810034	Bushing	HB 90, 99, 100, 200, 300, 1900
HEM50-810225	50-810225	Clamp Assy.	HB 90, 99, 100, 200
HEM50-810225-6	50-810225-6	Clamp Assy.	HB 90, 99, 200, 300
HEM50-810225-10	50-810225-10	Clamp Assy.	HB 1900
HEM50-810315	50-810315	Hook	HB 90
HEM50-810324-1	50-810324-1	Pin	HB 90, 99, 100
HEM50-810326	50-810326	Bearing	HB 90, 99, 100, 200, 300, 1900
HEM50-810331-1	50-810331-1	Orifice	HB 99, 100
HEM50-810331-3	50-810331-3	Orifice	HB 200
HEM50-810331-7	50-810331-7	Orifice	HB 1900
HEM50-810331-9	50-810331-9	Orifice	HB 200, 300
HEM50-810334	50-810334	Roller	HB 90, 99, 100, 200, 300
HEM50-810335-3	50-810335-3	Bushing	HB 90, 99, 100, 200, 1900
HEM50-810338-5	50-810338-5	Hook	HB 90, 99, 200
HEM50-810347	50-810347	Retainer Assy	HB 90, 99, 100, 200, 300, 1900
HEM50-810347-1	50-810347-1	Retainer	HB 90, 99, 100, 200, 300, 1900
HEM50-810353	50-810353	Spring Guide	90, 99, 100, 200
HEM50-810354	50-810354	Spring Guide	90, 99, 100, 200
HEM50-810356	50-810356	Shim	HB 90, 99, 100, 200, 1900
HEM50-820024	50-820024	Shim	HB 90, 99, 200, 300, 1900
HEM50-820205-13	50-820205-13	Drag Leg	HB 90, 100, 200
HEM50-820205-17	50-820205-17	Drag Leg	HB 90, 100, 200, 1900
HEM50-820205-41	50-820205-41	Drag Leg	HB 1900
HEM50-820240	50-820240	Steering Stop	HB 90, 99, 100, 200, 300, 1900
HEM50-921587-0011	50-921587-0011	Gasket	HB 200, 300
HEM54-333	54-333	Sleeve	DHC-7-100
HEM54-398	54-398	Sleeve	DHC-8-100/200/300, Cessna 650
HEM54-399	54-399	Piston Sleeve	DHC-8-100/200/300
HEM54-479	54-479	Sleeve	ATR-42-200/300
HEM54-538	54-538	Sleeve	DHC-8-400
HEM56-1178	56-1178	Back-Up Ring	DHC-8-400
HEM60-384016-11	60-384016-11	Retaining Ring	HB 1900
HEM60-384016-5	60-384016-5	Retaining Ring	HB 90, 99, 100, 200, 300, 1900
HEM68-450	68-450	O-Ring	DHC-8-400
HEM68-1125	68-1125	O-Ring	DHC-8-400
HEM68-216	68-216	O-Ring	DHC-8-400
HEM68-269	68-269	O-Ring	DHC-8-400
HEM68-1551	68-1551	Back-Up Ring	DHC-8-400
HEM68-1569	68-1569	O-Ring	DHC-8-400
HEM68-1264	68-1264	O-Ring	HB 560
HEM68-1413	68-1413	O-Ring	HB 750
HEM68-1448	68-1448	O-Ring	DHC-8-400
HEM68-1482	68-1482	O-Ring	HB 525, 560
HEM68-448	68-448	O-Ring	HB 680, 700, 750
HEM7235MT987N	7235MT987N	Seal	HB 1900
HEM7335FT972P3	7335FT972P3	Seal	HB 1900
HEM74-808	74-808	Piston	DHC-8-100/200/300
HEM90-820010-1	90-820010-1	Bushing	HB 90, 99, 100, 200, 300, 1900
HEM90-820011-1	90-820011-1	Bolt	HB 99, 100, 200, 1900
HEM90-820011-5	90-820011-5	Bolt	HB 90, 200, 1900
HEM97-820000-17	97-820000-17	Shim	HB 90, 99, 200, 300, 1900
HEM99-810022-7	99-810022-7	Plate	HB 90, 99, 200
HEM99-810032	99-810032	Bracket	HB 90, 99, 100, 200, 300, 1900
HEM99-810045	99-810045	Link	HB 90, 99, 100, 200
HEM99-810061-1	99-810061-1	Bolt Assembly	HB 99, 100, 200
HEM99-810061-3	99-810061-3	Bolt	HB 99, 100, 200
HEM99-810062-3	99-810062-3	Lube Bolt	HB 99, 100
HEM99-810064-3	99-810064-3	Bushing	HB 90, 99, 200, 300, 1900
HEM99-810065-1	99-810065-1	Pin	HB 90, 99, 100
HEM99-810067-1	99-810067-1	Bolt	HB 90, 99, 100
HEM99-810067-3	99-810067-3	Bolt	HB 90, 99, 100, 200
HEM99-810068-1	99-810068-1	Bushing	HB 99, 100, 200
HEM99-820103	99-820103	Shim	HB 90, 99, 200, 300
HEM99-820110-9	99-820110-9	Pin	HB 90, 100, 200, 300, 1900
HEMA508-1	A508-1	Boot	Saab 340