



ROTORCRAFT

Inlet Barrier Filter Consumables and Spare Parts

Consumables

FAA Certified Oil

100101-000 1 gallon

100105-000 5 gallon

FAA Certified Cleaner

100201-000 1 gallon

100205-000 5 gallon

100800-101 IBF Filter Cleaning Kit

includes:

1 gallon of oil

1 gallon of cleaner/degreaser

16 oz. bottle and spout

Chem. Sprayer

Seamer Pliers -2 inch and 6 inch

Spare Filters

124300-101 AW109E/S Spare Filter Assembly Left

124300-102 AW109E/S Spare Filter Assembly Right

119300-101 AW119 Filter Assembly, Upper

119350-101 AW119 Filter Assembly, Side (2 Required for Complete Set)

122300-101 AW139 Spare Filter Assembly Upper (2 Required)

122350-101 AW139 Spare Filter Assembly Lower (2 Required)

111300-103 Bell 205A1/UH-1H Filter Assembly (4 Required for Complete Set)

109200-101 Bell 206B, OH-58A/C Spare Filter Assembly Left

109200-102 Bell 206B, OH-58A/C Spare Filter Assembly Right

106200-101 Bell 407/206L-1/3/4 Spare Filter Assembly w/Wash Tube

106201-103 Bell 407/206L-1/3/4 Spare Filter Assembly without Wash Tube

118300-101 Bell 430 Spare Filter Assembly Upper Left

118300-102 Bell 430 Spare Filter Assembly Upper Right

118350-101 Bell 430 Spare Filter Assembly Forward Left

118350-102 Bell 430 Spare Filter Assembly Forward Right

112300-101 AS350 Spare Filter Assembly - Dzus Fastener

112300-105 AS350 Spare Filter Assembly - WES Fastener

121300-103 EC130 (AS 350B4) Spare Filter Assembly

102400-101 MD500 Spare Upper Filter Assembly

102450-101 MD500 Spare Forward Filter Assembly

114300-101 MD900 Spare Filter Assembly Left

114300-102 MD900 Spare Filter Assembly Right