



AIRCRAFT PARTS & SERVICES



## Agusta Application List

P: 705-742-9725

[www.kadexaero.com](http://www.kadexaero.com)

Contact:

Description	OEM PN	Seginus PN	NHA Description	NHA PN	Aircraft	Aircraft Model Number
Bearing	150SG1052-B	EH150SG1052-B	STARTER GENERATOR	200SG MODEL LIST	Agusta S,p.A.	A019A
Bearing	150SG1052-B	EH150SG1052-B	STARTER GENERATOR	200SG MODEL LIST	Agusta S,p.A.	A109
Drive Shaft Assembly	150SG1103-2	150SG1103-2EH	STARTER GENERATOR	150SG115Q, 150SG117Q, 150SG123Q, 150SG144Q, 150SG125Q-2, 150SG117Q-3, 150SG117Q-4,	Agusta	A109
Brushes	150SG1009-5	150SG1009-5EH	STARTER GENERATOR	150SG111Q, 150SG116Q, 150SG117Q-4, 150SG120Q, 150SG125Q-2, 150SG114Q, 150SG117Q, 150SG118Q, 150SG122Q, 150SG144Q, 150SG115Q, 150SF117Q-3, 150SG119Q, 150SG125Q, 160SG137Q-2, 160SG139Q-2, 160SG140Q, 160SG141Q	Agusta	A109
Brushes	200SGL1009-3	200SGL1009-3EH	STARTER GENERATOR	200SGL111Q, 200SGL118Q, 200SGL129Q, 200SGL129Q (5), 200SGL142Q, 200SGL115Q, 200SGL119Q, 200SGL129Q (1), 200SGL130Q, 200SGL147Q, 200SGL115Q-2, 200SGL119Q-2, 200SGL129Q (3), 200SGL131Q	Agusta	A109
Brushes	200SGL1009-10X2	200SGL1009-10X2EH	STARTER GENERATOR	200SGL111Q, 200SGL117Q, 200SGL129Q, 200SGL130Q, 200SGL132Q-4, 200SGL144Q, 200SGL147Q-3, 200SGL111Q-3, 200SGL118Q, 200SGL129Q (4), 200SGL132Q, 200SGL132Q-5, 200SGL147Q, 200SGL151Q, 200SGL115Q, 200SGL124Q, 200SGL129Q (8), 200SGL132Q-3, 200SGL142Q, 200SGL147Q-2, 200SGL153Q	Agusta	A109
Bearing	03-6009-23	EH03-6009-23	STARTER GENERATOR	23088-008	Agusta S,p.A.	A109A
Brush	23033-1141	EH23033-1141	STARTER GENERATOR	23032-020, 23032-022	Agusta S,p.A.	A109A
Drive Shaft Assembly	150SG1103-2	150SG1103-2EH	STARTER GENERATOR	150SG115Q, 150SG117Q, 150SG123Q, 150SG144Q, 150SG125Q-2, 150SG117Q-3, 150SG117Q-4,	Agusta	A109A
Brushes	150SG1009-5	150SG1009-5EH	STARTER GENERATOR	150SG111Q, 150SG116Q, 150SG117Q-4, 150SG120Q, 150SG125Q-2, 150SG114Q, 150SG117Q, 150SG118Q, 150SG122Q, 150SG144Q, 150SG115Q, 150SF117Q-3, 150SG119Q, 150SG125Q, 160SG137Q-2, 160SG139Q-2, 160SG140Q, 160SG141Q	Agusta	A109A
Bearing	03-6009-23	EH03-6009-23	STARTER GENERATOR	23088-008	Agusta S,p.A.	A109C
Bearing	150SG1052-B	EH150SG1052-B	STARTER GENERATOR	200SG MODEL LIST	Agusta S,p.A.	A109C
Drive Shaft Assembly	150SG1103-2	150SG1103-2EH	STARTER GENERATOR	150SG115Q, 150SG117Q, 150SG123Q, 150SG144Q, 150SG125Q-2, 150SG117Q-3, 150SG117Q-4,	Agusta	A109C
Brushes	150SG1009-5	150SG1009-5EH	STARTER GENERATOR	150SG111Q, 150SG116Q, 150SG117Q-4, 150SG120Q, 150SG125Q-2, 150SG114Q, 150SG117Q, 150SG118Q, 150SG122Q, 150SG144Q, 150SG115Q, 150SF117Q-3, 150SG119Q, 150SG125Q, 160SG137Q-2, 160SG139Q-2, 160SG140Q, 160SG141Q	Agusta	A109C
Brushes	150SG1009-20XL2	150SG1009-20XL2EH	STARTER GENERATOR	150SG132Q, 160SG136Q, 160SG137Q, 160SG139Q, 160SG142Q	Agusta	A109C

Brushes	150SG1009-20XL2	150SG1009-20XL2EH	STARTER GENERATOR	150SG132Q, 160SG136Q, 160SG137Q, 160SG139Q, 160SG142Q	Agusta	A109K
Brushes	200SGL1009	200SGL1009EH	STARTER GENERATOR	200SGL111Q, 200SGL112Q, 200SGL115Q-2, 200SGL119Q, 200SGL121Q, 200SGL129Q, 200SGL131Q (4), 200SGL131Q, 200SGL142Q, 200SGL147Q, 200SGL111Q-2, 200SGL114Q, 200SGL117Q, 200SGL119Q-2, 200SGL124Q, 200SGL129Q (8), 200SGL131Q-2, 200SGL144Q, 200SGL111Q-3, 200SGL115Q, 200SGL118Q, 200SGL120Q, 200SGL129Q, 200SGL130Q, 200SGL132Q, 200SGL145Q	Agusta	A119
Brushes	200SGL1009-3	200SGL1009-3EH	STARTER GENERATOR	200SGL111Q, 200SGL118Q, 200SGL129Q, 200SGL129Q (5), 200SGL142Q, 200SGL115Q, 200SGL119Q, 200SGL129Q (1), 200SGL130Q, 200SGL147Q, 200SGL115Q-2, 200SGL119Q-2, 200SGL129Q (3), 200SGL131Q	Agusta	A119
Brushes	200SGL1009-10X2	200SGL1009-10X2EH	STARTER GENERATOR	200SGL111Q, 200SGL117Q, 200SGL129Q, 200SGL130Q, 200SGL132Q-4, 200SGL144Q, 200SGL147Q-3, 200SGL111Q-3, 200SGL118Q, 200SGL129Q (4), 200SGL132Q, 200SGL132Q-5, 200SGL147Q, 200SGL151Q, 200SGL115Q, 200SGL124Q, 200SGL129Q (8), 200SGL132Q-3, 200SGL142Q, 200SGL147Q-2, 200SGL153Q	Agusta	A119
Bearing	250SG1052-B	EH250SG1052-B	STARTER GENERATOR	300SG MODEL LIST	Agusta S,p.A.	AB139
Magnetic Speed Pick-Up	SP-1	EHSP-1	STARTER GENERATOR	23080-SERIES, 23081-SERIES, 23085-SERIES, 23095-SERIES, 8260-121, 8160-121, 200SG-SERIES, 300SG SERIES, 400SG-SERIES	Agusta S,p.A.	AB139
Drive Shaft Assembly	300SGL1103-4	300SGL1103-4EH	STARTER GENERATOR	300SGL115Q, 300SGL126Q, 300SGL138Q-2, 300SGL138Q-5, 300SGL145Q, 300SGL146Q, 300SGL152Q	Agusta	AB139
Brushes	300SGL1009-5	300SGL1009-5EH	STARTER GENERATOR	300SGL111Q-1, 300SGL115Q, 300SGL118Q, 300SGL127Q-2, 300SGL129Q, 300SGL138Q-4, 300SGL146Q, 300SGL150Q, 300SGL162Q, 300SGL111Q-2, 300SGL116Q, 300SGL126Q, 300SGL127Q-3, 300SGL129Q-2, 300SGL138Q-5, 300SGL146Q-2, 300SGL153Q, 300SGL162Q-2, 300SGL114Q, 300SGL116Q-2, 300SGL127Q-1, 300SGL127Q-4, 300SGL138Q-2, 300SGL139Q, 300SGL146Q-3, 300SGL157Q, 300SGL162Q-3	Agusta	AB139
Brush	30300-1285	EH30300-1285	STARTER GENERATOR	23048-016, 23046 Series, 23048 Series	Agusta S,p.A.	AB412
Brushes	200SGL1009	200SGL1009EH	STARTER GENERATOR	200SGL111Q, 200SGL112Q, 200SGL115Q-2, 200SGL119Q, 200SGL121Q, 200SGL129Q, 200SGL131Q (4), 200SGL131Q, 200SGL142Q, 200SGL147Q, 200SGL111Q-2, 200SGL114Q, 200SGL117Q, 200SGL119Q-2, 200SGL124Q, 200SGL129Q (8), 200SGL131Q-2, 200SGL144Q, 200SGL111Q-3, 200SGL115Q, 200SGL118Q, 200SGL120Q, 200SGL129Q, 200SGL130Q, 200SGL132Q, 200SGL145Q	Agusta	AW119 MKII
Brushes	200SGL1009-3	200SGL1009-3EH	STARTER GENERATOR	200SGL111Q, 200SGL118Q, 200SGL129Q, 200SGL129Q (5), 200SGL142Q, 200SGL115Q, 200SGL119Q, 200SGL129Q (1), 200SGL130Q, 200SGL147Q, 200SGL115Q-2, 200SGL119Q-2, 200SGL129Q (3), 200SGL131Q	Agusta	AW119 MKII

Brushes	200SGL1009-10X2	200SGL1009-10X2EH	STARTER GENERATOR	200SGL111Q, 200SGL117Q, 200SGL129Q, 200SGL130Q, 200SGL132Q-4, 200SGL144Q, 200SGL147Q-3, 200SGL111Q-3, 200SGL118Q, 200SGL129Q (4), 200SGL132Q, 200SGL132Q-5, 200SGL147Q, 200SGL151Q, 200SGL115Q, 200SGL124Q, 200SGL129Q (8), 200SGL132Q-3, 200SGL142Q, 200SGL147Q-2, 200SGL153Q	Agusta	AW119 MKII
Magnetic Speed Pick-Up	SP-1	EHSP-1	STARTER GENERATOR	23080-SERIES, 23081-SERIES, 23085-SERIES, 23095-SERIES, 8260-121, 8160-121, 200SG-SERIES, 300SG SERIES, 400SG-SERIES	Agusta S,p.A.	AW139
Drive Shaft Assembly	300SGL1103-4	300SGL1103-4EH	STARTER GENERATOR	300SGL115Q, 300SGL126Q, 300SGL138Q-2, 300SGL138Q-5, 300SGL145Q, 300SGL146Q, 300SGL152Q	Agusta	AW139
Brushes	300SGL1009-5	300SGL1009-5EH	STARTER GENERATOR	300SGL111Q-1, 300SGL115Q, 300SGL118Q, 300SGL127Q-2, 300SGL129Q, 300SGL138Q-4, 300SGL146Q, 300SGL150Q, 300SGL162Q, 300SGL111Q-2, 300SGL116Q, 300SGL126Q, 300SGL127Q-3, 300SGL129Q-2, 300SGL138Q-5, 300SGL146Q-2, 300SGL153Q, 300SGL162Q-2, 300SGL114Q, 300SGL116Q-2, 300SGL127Q-1, 300SGL127Q-4, 300SGL138Q-2, 300SGL139Q, 300SGL146Q-3, 300SGL157Q, 300SGL162Q-3	Agusta	AW139
Bearing	410964	410964EH	STARTER GENERATOR	524-060* (61, 62)	Agusta S,p.A.	Model A109
Bearing	410997	410997EH	STARTER GENERATOR	524-060* (61, 62)	Agusta S,p.A.	Model A109
Bearing	410964	410964EH	STARTER GENERATOR	524-060* (61, 62)	Agusta S,p.A.	Model A109A
Bearing	410997	410997EH	STARTER GENERATOR	524-060* (61, 62)	Agusta S,p.A.	Model A109A
Bearing	03-6009-23	EH03-6009-23	STARTER GENERATOR	23088-008	Agusta S,p.A.	Model A109A
Bearing	03-6009-23	EH03-6009-23	STARTER GENERATOR	23088-008	Agusta S,p.A.	Model A109A
Bearing	410964	410964EH	STARTER GENERATOR	524-060* (61, 62)	Agusta S,p.A.	Model A109A II
Bearing	410997	410997EH	STARTER GENERATOR	524-060* (61, 62)	Agusta S,p.A.	Model A109A II
Bearing	410964	410964EH	STARTER GENERATOR	524-060* (61, 62)	Agusta S,p.A.	Model A109C
Bearing	410997	410997EH	STARTER GENERATOR	524-060* (61, 62)	Agusta S,p.A.	Model A109C
Bearing	03-6009-23	EH03-6009-23	STARTER GENERATOR	23088-008	Agusta S,p.A.	Model A109C
Bearing	03-6009-23	EH03-6009-23	STARTER GENERATOR	23088-008	Agusta S,p.A.	Model A109C
Bearing	410964	410964EH	STARTER GENERATOR	524-060* (61, 62)	Agusta S,p.A.	Model A109E
Bearing	410997	410997EH	STARTER GENERATOR	524-060* (61, 62)	Agusta S,p.A.	Model A109E
Bearing	410964	410964EH	STARTER GENERATOR	524-060* (61, 62)	Agusta S,p.A.	Model A109K2
Bearing	410997	410997EH	STARTER GENERATOR	524-060* (61, 62)	Agusta S,p.A.	Model A109K2
Bearing	410964	410964EH	STARTER GENERATOR	524-060* (61, 62)	Agusta S,p.A.	Model A109S
Bearing	410997	410997EH	STARTER GENERATOR	524-060* (61, 62)	Agusta S,p.A.	Model A109S