



## Airbus Helicopter Application List

P: 705-742-9725

[www.kadexaero.com](http://www.kadexaero.com)

Contact:



Description	OEM PN	Seginus PN	NHA Description	NHA PN	Aircraft	Aircraft Model Number
Drive Shaft Assembly	150SG1103-7	150SG1103-7EH	STARTER GENERATOR	150SG122Q	Airbus Helicopter	AS350B
Brushes	150SG1009-5	150SG1009-5EH	STARTER GENERATOR	150SG111Q, 150SG116Q, 150SG117Q-4, 150SG120Q, 150SG125Q-2, 150SG114Q, 150SG117Q, 150SG118Q, 150SG122Q, 150SG144Q, 150SG115Q, 150SF117Q-3, 150SG119Q, 150SG125Q, 160SG137Q-2, 160SG139Q-2, 160SG140Q, 160SG141Q	Airbus Helicopter	AS350B
Brushes	200SGL1009	200SGL1009EH	STARTER GENERATOR	200SGL11Q, 200SGL112Q, 20SGL115Q-2, 200SGL119Q, 200SGL121Q, 200SGL129Q, 200SGL131Q (4), 200SGL131Q, 200SGL142Q, 200SGL147Q, 200SGL111Q-2, 200SGL114Q, 200SGL117Q, 200SGL119Q-2, 200SGL124Q, 200SGL129Q (8), 200SGL131Q-2, 200SGL144Q, 200SGL111Q-3, 200SGL115Q, 200SGL118Q, 200SGL120Q, 200SGL129Q, 200SGL130Q, 200SGL132Q, 200SGL145Q	Airbus Helicopter	AS350B
Brushes	200SGL1009-3	200SGL1009-3EH	STARTER GENERATOR	200SGL111Q, 200SGL118Q, 200SGL129Q, 200SGL129Q (5), 200SGL142Q, 200SGL115Q, 200SGL119Q, 200SGL129Q (1), 200SGL130Q, 200SGL147Q, 200SGL115Q-2, 200SGL119Q-2, 200SGL129Q (3), 200SGL131Q	Airbus Helicopter	AS350B
Brushes	200SGL1009-10X2	200SGL1009-10X2EH	STARTER GENERATOR	200SGL111Q, 200SGL117Q, 200SGL129Q, 200SGL130Q, 200SGL132Q-4, 200SGL144Q, 200SGL147Q-3, 200SGL111Q-3, 200SGL118Q, 200SGL129Q (4), 200SGL132Q, 200SGL132Q-5, 200SGL147Q, 200SGL151Q, 200SGL115Q, 200SGL124Q, 200SGL129Q (8), 200SGL132Q-3, 200SGL142Q, 200SGL147Q-2, 200SGL153Q	Airbus Helicopter	AS350B
Drive Shaft Assembly	150SG1103-7	150SG1103-7EH	STARTER GENERATOR	150SG122Q	Airbus Helicopter	AS350B1
Brushes	150SG1009-5	150SG1009-5EH	STARTER GENERATOR	150SG111Q, 150SG116Q, 150SG117Q-4, 150SG120Q, 150SG125Q-2, 150SG114Q, 150SG117Q, 150SG118Q, 150SG122Q, 150SG144Q, 150SG115Q, 150SF117Q-3, 150SG119Q, 150SG125Q, 160SG137Q-2, 160SG139Q-2, 160SG140Q, 160SG141Q	Airbus Helicopter	AS350B1
Brushes	200SGL1009	200SGL1009EH	STARTER GENERATOR	200SGL11Q, 200SGL112Q, 20SGL115Q-2, 200SGL119Q, 200SGL121Q, 200SGL129Q, 200SGL131Q (4), 200SGL131Q, 200SGL142Q, 200SGL147Q, 200SGL111Q-2, 200SGL114Q, 200SGL117Q, 200SGL119Q-2, 200SGL124Q, 200SGL129Q (8), 200SGL131Q-2, 200SGL144Q, 200SGL111Q-3, 200SGL115Q, 200SGL118Q, 200SGL120Q, 200SGL129Q, 200SGL130Q, 200SGL132Q, 200SGL145Q	Airbus Helicopter	AS350B1

Brushes	200SGL1009-3	200SGL1009-3EH	STARTER GENERATOR	200SGL111Q, 200SGL118Q, 200SGL129Q, 200SGL129Q (5), 200SGL142Q, 200SGL115Q, 200SGL119Q, 200SGL129Q (1), 200SGL130Q, 200SGL147Q, 200SGL115Q-2, 200SGL119Q-2, 200SGL129Q (3), 200SGL131Q	Airbus Helicopter	AS350B1
Brushes	200SGL1009-10X2	200SGL1009-10X2EH	STARTER GENERATOR	200SGL111Q, 200SGL117Q, 200SGL129Q, 200SGL130Q, 200SGL132Q-4, 200SGL144Q, 200SGL147Q-3, 200SGL111Q-3, 200SGL118Q, 200SGL129Q (4), 200SGL132Q, 200SGL132Q-5, 200SGL147Q, 200SGL151Q, 200SGL115Q, 200SGL124Q, 200SGL129Q (8), 200SGL132Q-3, 200SGL142Q, 200SGL147Q-2, 200SGL153Q	Airbus Helicopter	AS350B1
Drive Shaft Assembly	150SG1103-7	150SG1103-7EH	STARTER GENERATOR	150SG122Q	Airbus Helicopter	AS350B2
Brushes	150SG1009-5	150SG1009-5EH	STARTER GENERATOR	150SG111Q, 150SG116Q, 150SG117Q-4, 150SG120Q, 150SG125Q-2, 150SG114Q, 150SG117Q, 150SG118Q, 150SG122Q, 150SG144Q, 150SG115Q, 150SF117Q-3, 150SG119Q, 150SG125Q, 160SG137Q-2, 160SG139Q-2, 160SG140Q, 160SG141Q	Airbus Helicopter	AS350B2
Brushes	200SGL1009	200SGL1009EH	STARTER GENERATOR	200SGL11Q, 200SGL112Q, 20SGL115Q-2, 200SGL119Q, 200SGL121Q, 200SGL129Q, 200SGL131Q (4), 200SGL131Q, 200SGL142Q, 200SGL147Q, 200SGL111Q-2, 200SGL114Q, 200SGL117Q, 200SGL119Q-2, 200SGL124Q, 200SGL129Q (8), 200SGL131Q-2, 200SGL144Q, 200SGL111Q-3, 200SGL115Q, 200SGL118Q, 200SGL120Q, 200SGL129Q, 200SGL130Q, 200SGL132Q, 200SGL145Q	Airbus Helicopter	AS350B2
Brushes	200SGL1009-3	200SGL1009-3EH	STARTER GENERATOR	200SGL111Q, 200SGL118Q, 200SGL129Q, 200SGL129Q (5), 200SGL142Q, 200SGL115Q, 200SGL119Q, 200SGL129Q (1), 200SGL130Q, 200SGL147Q, 200SGL115Q-2, 200SGL119Q-2, 200SGL129Q (3), 200SGL131Q	Airbus Helicopter	AS350B2
Brushes	200SGL1009-10X2	200SGL1009-10X2EH	STARTER GENERATOR	200SGL111Q, 200SGL117Q, 200SGL129Q, 200SGL130Q, 200SGL132Q-4, 200SGL144Q, 200SGL147Q-3, 200SGL111Q-3, 200SGL118Q, 200SGL129Q (4), 200SGL132Q, 200SGL132Q-5, 200SGL147Q, 200SGL151Q, 200SGL115Q, 200SGL124Q, 200SGL129Q (8), 200SGL132Q-3, 200SGL142Q, 200SGL147Q-2, 200SGL153Q	Airbus Helicopter	AS350B2
Bearing	B320050L	EHB320050L	STARTER GENERATOR	8260-121, 8260-123	Airbus	AS350B2
Drive Shaft Assembly	150SG1103-7	150SG1103-7EH	STARTER GENERATOR	150SG122Q	Airbus Helicopter	AS350B3
Brushes	150SG1009-5	150SG1009-5EH	STARTER GENERATOR	150SG111Q, 150SG116Q, 150SG117Q-4, 150SG120Q, 150SG125Q-2, 150SG114Q, 150SG117Q, 150SG118Q, 150SG122Q, 150SG144Q, 150SG115Q, 150SF117Q-3, 150SG119Q, 150SG125Q, 160SG137Q-2, 160SG139Q-2, 160SG140Q, 160SG141Q	Airbus Helicopter	AS350B3

Brushes	200SGL1009	200SGL1009EH	STARTER GENERATOR	200SGL11Q, 200SGL112Q, 20SGL115Q-2, 200SGL119Q, 200SGL121Q, 200SGL129Q, 200SGL131Q (4), 200SGL131Q, 200SGL142Q, 200SGL147Q, 200SGL111Q-2, 200SGL114Q, 200SGL117Q, 200SGL119Q-2, 200SGL124Q, 200SGL129Q (8), 200SGL131Q-2, 200SGL144Q, 200SGL111Q-3, 200SGL115Q, 200SGL118Q, 200SGL120Q, 200SGL129Q, 200SGL130Q, 200SGL132Q, 200SGL145Q	Airbus Helicopter	AS350B3
Brushes	200SGL1009-3	200SGL1009-3EH	STARTER GENERATOR	200SGL111Q, 200SGL118Q, 200SGL129Q, 200SGL129Q (5), 200SGL142Q, 200SGL115Q, 200SGL119Q, 200SGL129Q (1), 200SGL130Q, 200SGL147Q, 200SGL115Q-2, 200SGL119Q-2, 200SGL129Q (3), 200SGL131Q	Airbus Helicopter	AS350B3
Brushes	200SGL1009-10X2	200SGL1009-10X2EH	STARTER GENERATOR	200SGL111Q, 200SGL117Q, 200SGL129Q, 200SGL130Q, 200SGL132Q-4, 200SGL144Q, 200SGL147Q-3, 200SGL111Q-3, 200SGL118Q, 200SGL129Q (4), 200SGL132Q, 200SGL132Q-5, 200SGL147Q, 200SGL151Q, 200SGL115Q, 200SGL124Q, 200SGL129Q (8), 200SGL132Q-3, 200SGL142Q, 200SGL147Q-2, 200SGL153Q	Airbus Helicopter	AS350B3
Bearing	B320050L	EHB320050L	STARTER GENERATOR	8260-121, 8260-123	Airbus	AS350B3
Drive Shaft Assembly	150SG1103-7	150SG1103-7EH	STARTER GENERATOR	150SG122Q	Airbus Helicopter	AS350BA
Brushes	150SG1009-5	150SG1009-5EH	STARTER GENERATOR	150SG111Q, 150SG116Q, 150SG117Q-4, 150SG120Q, 150SG125Q-2, 150SG114Q, 150SG117Q, 150SG118Q, 150SG122Q, 150SG144Q, 150SG115Q, 150SF117Q-3, 150SG119Q, 150SG125Q, 160SG137Q-2, 160SG139Q-2, 160SG140Q, 160SG141Q	Airbus Helicopter	AS350BA
Brushes	200SGL1009	200SGL1009EH	STARTER GENERATOR	200SGL11Q, 200SGL112Q, 20SGL115Q-2, 200SGL119Q, 200SGL121Q, 200SGL129Q, 200SGL131Q (4), 200SGL131Q, 200SGL142Q, 200SGL147Q, 200SGL111Q-2, 200SGL114Q, 200SGL117Q, 200SGL119Q-2, 200SGL124Q, 200SGL129Q (8), 200SGL131Q-2, 200SGL144Q, 200SGL111Q-3, 200SGL115Q, 200SGL118Q, 200SGL120Q, 200SGL129Q, 200SGL130Q, 200SGL132Q, 200SGL145Q	Airbus Helicopter	AS350BA
Brushes	200SGL1009-3	200SGL1009-3EH	STARTER GENERATOR	200SGL111Q, 200SGL118Q, 200SGL129Q, 200SGL129Q (5), 200SGL142Q, 200SGL115Q, 200SGL119Q, 200SGL129Q (1), 200SGL130Q, 200SGL147Q, 200SGL115Q-2, 200SGL119Q-2, 200SGL129Q (3), 200SGL131Q	Airbus Helicopter	AS350BA
Brushes	200SGL1009-10X2	200SGL1009-10X2EH	STARTER GENERATOR	200SGL111Q, 200SGL117Q, 200SGL129Q, 200SGL130Q, 200SGL132Q-4, 200SGL144Q, 200SGL147Q-3, 200SGL111Q-3, 200SGL118Q, 200SGL129Q (4), 200SGL132Q, 200SGL132Q-5, 200SGL147Q, 200SGL151Q, 200SGL115Q, 200SGL124Q, 200SGL129Q (8), 200SGL132Q-3, 200SGL142Q, 200SGL147Q-2, 200SGL153Q	Airbus Helicopter	AS350BA
Bearing	B320050L	EHB320050L	STARTER GENERATOR	8260-121, 8260-123	Airbus	AS350BA

Bearing	03-6009-23	EH03-6009-23	STARTER GENERATOR	23088-008	Airbus Helicopters	AS350C
Bearing	03-6009-23	EH03-6009-23	STARTER GENERATOR	23088-008	Airbus Helicopters	AS350C
Drive Shaft Assembly	150SG1103-7	150SG1103-7EH	STARTER GENERATOR	150SG122Q	Airbus Helicopter	AS350C
Brushes	150SG1009-5	150SG1009-5EH	STARTER GENERATOR	150SG111Q, 150SG116Q, 150SG117Q-4, 150SG120Q, 150SG125Q-2, 150SG114Q, 150SG117Q, 150SG118Q, 150SG122Q, 150SG144Q, 150SG115Q, 150SF117Q-3, 150SG119Q, 150SG125Q, 160SG137Q-2, 160SG139Q-2, 160SG140Q, 160SG141Q	Airbus Helicopter	AS350C
Brushes	200SGL1009	200SGL1009EH	STARTER GENERATOR	200SGL11Q, 200SGL112Q, 20SGL115Q-2, 200SGL119Q, 200SGL121Q, 200SGL129Q, 200SGL131Q (4), 200SGL131Q, 200SGL142Q, 200SGL147Q, 200SGL111Q-2, 200SGL114Q, 200SGL117Q, 200SGL119Q-2, 200SGL124Q, 200SGL129Q (8), 200SGL131Q-2, 200SGL144Q, 200SGL111Q-3, 200SGL115Q, 200SGL118Q, 200SGL120Q, 200SGL129Q, 200SGL130Q, 200SGL132Q, 200SGL145Q	Airbus Helicopter	AS350C
Brushes	200SGL1009-3	200SGL1009-3EH	STARTER GENERATOR	200SGL111Q, 200SGL118Q, 200SGL129Q, 200SGL129Q (5), 200SGL142Q, 200SGL115Q, 200SGL119Q, 200SGL129Q (1), 200SGL130Q, 200SGL147Q, 200SGL115Q-2, 200SGL119Q-2, 200SGL129Q (3), 200SGL131Q	Airbus Helicopter	AS350C
Brushes	200SGL1009-10X2	200SGL1009-10X2EH	STARTER GENERATOR	200SGL111Q, 200SGL117Q, 200SGL129Q, 200SGL130Q, 200SGL132Q-4, 200SGL144Q, 200SGL147Q-3, 200SGL111Q-3, 200SGL118Q, 200SGL129Q (4), 200SGL132Q, 200SGL132Q-5, 200SGL147Q, 200SGL151Q, 200SGL115Q, 200SGL124Q, 200SGL129Q (8), 200SGL132Q-3, 200SGL142Q, 200SGL147Q-2, 200SGL153Q	Airbus Helicopter	AS350C
Bearing	03-6009-23	EH03-6009-23	STARTER GENERATOR	23088-008	Airbus Helicopters	AS350D
Bearing	03-6009-23	EH03-6009-23	STARTER GENERATOR	23088-008	Airbus Helicopters	AS350D
Drive Shaft Assembly	150SG1103-7	150SG1103-7EH	STARTER GENERATOR	150SG122Q	Airbus Helicopter	AS350D
Brushes	150SG1009-5	150SG1009-5EH	STARTER GENERATOR	150SG111Q, 150SG116Q, 150SG117Q-4, 150SG120Q, 150SG125Q-2, 150SG114Q, 150SG117Q, 150SG118Q, 150SG122Q, 150SG144Q, 150SG115Q, 150SF117Q-3, 150SG119Q, 150SG125Q, 160SG137Q-2, 160SG139Q-2, 160SG140Q, 160SG141Q	Airbus Helicopter	AS350D
Brushes	200SGL1009	200SGL1009EH	STARTER GENERATOR	200SGL11Q, 200SGL112Q, 20SGL115Q-2, 200SGL119Q, 200SGL121Q, 200SGL129Q, 200SGL131Q (4), 200SGL131Q, 200SGL142Q, 200SGL147Q, 200SGL111Q-2, 200SGL114Q, 200SGL117Q, 200SGL119Q-2, 200SGL124Q, 200SGL129Q (8), 200SGL131Q-2, 200SGL144Q, 200SGL111Q-3, 200SGL115Q, 200SGL118Q, 200SGL120Q, 200SGL129Q, 200SGL130Q, 200SGL132Q, 200SGL145Q	Airbus Helicopter	AS350D

Brushes	200SGL1009-3	200SGL1009-3EH	STARTER GENERATOR	200SGL111Q, 200SGL118Q, 200SGL129Q, 200SGL129Q (5), 200SGL142Q, 200SGL115Q, 200SGL119Q, 200SGL129Q (1), 200SGL130Q, 200SGL147Q, 200SGL115Q-2, 200SGL119Q-2, 200SGL129Q (3), 200SGL131Q	Airbus Helicopter	AS350D
Brushes	200SGL1009-10X2	200SGL1009-10X2EH	STARTER GENERATOR	200SGL111Q, 200SGL117Q, 200SGL129Q, 200SGL130Q, 200SGL132Q-4, 200SGL144Q, 200SGL147Q-3, 200SGL111Q-3, 200SGL118Q, 200SGL129Q (4), 200SGL132Q, 200SGL132Q-5, 200SGL147Q, 200SGL151Q, 200SGL115Q, 200SGL124Q, 200SGL129Q (8), 200SGL132Q-3, 200SGL142Q, 200SGL147Q-2, 200SGL153Q	Airbus Helicopter	AS350D
Bearing	B320050L	EHB320050L	STARTER GENERATOR	8260-121, 8260-123	Airbus	AS350D
Bearing	03-6009-23	EH03-6009-23	STARTER GENERATOR	23088-008	Airbus Helicopters	AS350D1
Bearing	03-6009-23	EH03-6009-23	STARTER GENERATOR	23088-008	Airbus Helicopters	AS350D1
Drive Shaft Assembly	150SG1103-7	150SG1103-7EH	STARTER GENERATOR	150SG122Q	Airbus Helicopter	AS350D1
Brushes	200SGL1009-3	200SGL1009-3EH	STARTER GENERATOR	200SGL111Q, 200SGL118Q, 200SGL129Q, 200SGL129Q (5), 200SGL142Q, 200SGL115Q, 200SGL119Q, 200SGL129Q (1), 200SGL130Q, 200SGL147Q, 200SGL115Q-2, 200SGL119Q-2, 200SGL129Q (3), 200SGL131Q	Airbus Helicopter	AS350D1
Brushes	200SGL1009-10X2	200SGL1009-10X2EH	STARTER GENERATOR	200SGL111Q, 200SGL117Q, 200SGL129Q, 200SGL130Q, 200SGL132Q-4, 200SGL144Q, 200SGL147Q-3, 200SGL111Q-3, 200SGL118Q, 200SGL129Q (4), 200SGL132Q, 200SGL132Q-5, 200SGL147Q, 200SGL151Q, 200SGL115Q, 200SGL124Q, 200SGL129Q (8), 200SGL132Q-3, 200SGL142Q, 200SGL147Q-2, 200SGL153Q	Airbus Helicopter	AS350D1
Brushes	150SG1009-5	150SG1009-5EH	STARTER GENERATOR	150SG111Q, 150SG116Q, 150SG117Q-4, 150SG120Q, 150SG125Q-2, 150SG114Q, 150SG117Q, 150SG118Q, 150SG122Q, 150SG144Q, 150SG115Q, 150SF117Q-3, 150SG119Q, 150SG125Q, 160SG137Q-2, 160SG139Q-2, 160SG140Q, 160SG141Q	Airbus Helicopter	AS350D1
Brushes	200SGL1009	200SGL1009EH	STARTER GENERATOR	200SGL11Q, 200SGL112Q, 20SGL115Q-2, 200SGL119Q, 200SGL121Q, 200SGL129Q, 200SGL131Q (4), 200SGL131Q, 200SGL142Q, 200SGL147Q, 200SGL111Q-2, 200SGL114Q, 200SGL117Q, 200SGL119Q-2, 200SGL124Q, 200SGL129Q (8), 200SGL131Q-2, 200SGL144Q, 200SGL111Q-3, 200SGL115Q, 200SGL118Q, 200SGL120Q, 200SGL129Q, 200SGL130Q, 200SGL132Q, 200SGL145Q	Airbus Helicopter	AS350D1
Bearing	03-6009-23	EH03-6009-23	STARTER GENERATOR	23088-008	Airbus Helicopters	AS355E
Drive Shaft Assembly	150SG1103-2	150SG1103-2EH	STARTER GENERATOR	150SG115Q, 150SG117Q, 150SG123Q, 150SG144Q, 150SG125Q-2, 150SG117Q-3, 150SG117Q-4,	Airbus Helicopter	AS355E
Bearing	03-6009-23	EH03-6009-23	STARTER GENERATOR	23088-008	Airbus Helicopters	AS355F
Drive Shaft Assembly	150SG1103-2	150SG1103-2EH	STARTER GENERATOR	150SG115Q, 150SG117Q, 150SG123Q, 150SG144Q, 150SG125Q-2, 150SG117Q-3, 150SG117Q-4,	Airbus Helicopter	AS355F
Bearing	03-6009-23	EH03-6009-23	STARTER GENERATOR	23088-008	Airbus Helicopters	AS355F1

Drive Shaft Assembly	150SG1103-2	150SG1103-2EH	STARTER GENERATOR	150SG115Q, 150SG117Q, 150SG123Q, 150SG144Q, 150SG125Q-2, 150SG117Q-3, 150SG117Q-4,	Airbus Helicopter	AS355F1
Bearing	03-6009-23	EH03-6009-23	STARTER GENERATOR	23088-008	Airbus Helicopters	AS355F2
Drive Shaft Assembly	150SG1103-2	150SG1103-2EH	STARTER GENERATOR	150SG115Q, 150SG117Q, 150SG123Q, 150SG144Q, 150SG125Q-2, 150SG117Q-3, 150SG117Q-4,	Airbus Helicopter	AS355N
Bearing	B320050L	EHB320050L	STARTER GENERATOR	8260-121, 8260-123	Airbus	AS355N
Drive Shaft Assembly	150SG1103-2	150SG1103-2EH	STARTER GENERATOR	150SG115Q, 150SG117Q, 150SG123Q, 150SG144Q, 150SG125Q-2, 150SG117Q-3, 150SG117Q-4,	Airbus Helicopter	AS355NP
Bearing	03-6009-23	EH03-6009-23	STARTER GENERATOR	23088-008	Airbus Helicopters Deutschland GmbH	BO-105A
Drive Shaft Assembly	150SG1103-2	150SG1103-2EH	STARTER GENERATOR	150SG115Q, 150SG117Q, 150SG123Q, 150SG144Q, 150SG125Q-2, 150SG117Q-3, 150SG117Q-4,	Airbus Helicopter Duetschland	BO-105A
Brushes	150SG1009-5	150SG1009-5EH	STARTER GENERATOR	150SG111Q, 150SG116Q, 150SG117Q-4, 150SG120Q, 150SG125Q-2, 150SG114Q, 150SG117Q, 150SG118Q, 150SG122Q, 150SG144Q, 150SG115Q, 150SF117Q-3, 150SG119Q, 150SG125Q, 160SG137Q-2, 160SG139Q-2, 160SG140Q, 160SG141Q	Airbus Helicopter Duetschland	BO-105A
Bearing	03-6009-23	EH03-6009-23	STARTER GENERATOR	23088-008	Airbus Helicopters Deutschland GmbH	BO-105C
Drive Shaft Assembly	150SG1103-2	150SG1103-2EH	STARTER GENERATOR	150SG115Q, 150SG117Q, 150SG123Q, 150SG144Q, 150SG125Q-2, 150SG117Q-3, 150SG117Q-4,	Airbus Helicopter Duetschland	BO-105C
Brushes	150SG1009-5	150SG1009-5EH	STARTER GENERATOR	150SG111Q, 150SG116Q, 150SG117Q-4, 150SG120Q, 150SG125Q-2, 150SG114Q, 150SG117Q, 150SG118Q, 150SG122Q, 150SG144Q, 150SG115Q, 150SF117Q-3, 150SG119Q, 150SG125Q, 160SG137Q-2, 160SG139Q-2, 160SG140Q, 160SG141Q	Airbus Helicopter Duetschland	BO-105C
Bearing	03-6009-23	EH03-6009-23	STARTER GENERATOR	23088-008	Airbus Helicopters Deutschland GmbH	BO-105LS A-3
Drive Shaft Assembly	150SG1103-2	150SG1103-2EH	STARTER GENERATOR	150SG115Q, 150SG117Q, 150SG123Q, 150SG144Q, 150SG125Q-2, 150SG117Q-3, 150SG117Q-4,	Airbus Helicopter Duetschland	BO-105S
Brushes	150SG1009-5	150SG1009-5EH	STARTER GENERATOR	150SG111Q, 150SG116Q, 150SG117Q-4, 150SG120Q, 150SG125Q-2, 150SG114Q, 150SG117Q, 150SG118Q, 150SG122Q, 150SG144Q, 150SG115Q, 150SF117Q-3, 150SG119Q, 150SG125Q, 160SG137Q-2, 160SG139Q-2, 160SG140Q, 160SG141Q	Airbus Helicopter Duetschland	BO-105S
Bearing	03-6009-23	EH03-6009-23	STARTER GENERATOR	23088-008	Airbus Helicopters Deutschland GmbH	BO-105S
Bearing	03-6009-23	EH03-6009-23	STARTER GENERATOR	23088-008	Airbus Helicopters Deutschland GmbH	BO-105S A-1
Drive Shaft Assembly	150SG1103-7	150SG1103-7EH	STARTER GENERATOR	150SG122Q	Airbus Helicopter	SA365N
Brushes	150SG1009-5	150SG1009-5EH	STARTER GENERATOR	150SG111Q, 150SG116Q, 150SG117Q-4, 150SG120Q, 150SG125Q-2, 150SG114Q, 150SG117Q, 150SG118Q, 150SG122Q, 150SG144Q, 150SG115Q, 150SF117Q-3, 150SG119Q, 150SG125Q, 160SG137Q-2, 160SG139Q-2, 160SG140Q, 160SG141Q	Airbus Helicopter	SA365N