



## ATR Application List

P: 705-742-9725

[www.kadexaero.com](http://www.kadexaero.com)

Contact:



Descrtiption	OEM PN	Seginus PN	NHA Description	NHA PN	Aircraft	Aircraft Model Number
Bearing	B320250L	EHB320250L	STARTER GENERATOR	8260-121, 8260-123	ATR	ATR-211
Bearing	B120052M	EHB120052M	AC GENERATOR	20032-2	ATR	ATR-211
Bearing	B320050L	EHB320050L	STARTER GENERATOR	8260-121, 8260-123	ATR	ATR-212
Bearing	B120052M	EHB120052M	AC GENERATOR	20032-2	ATR	ATR-212
Bearing	B320050L	EHB320050L	STARTER GENERATOR	8260-121, 8260-123	ATR	ATR-212A
Bearing	B120252M	EHB120252M	AC GENERATOR	20032-2	ATR	ATR-212A
Lining	P714154-1	P714154-1EH	STARTER GENERATOR	8160-121, 8260-121, 8260-123	ATR-GIE Avions de Transport Regional	ATR42-102
Bearing	B320050L	EHB320050L	STARTER GENERATOR	8260-121, 8260-123	ATR	ATR42-200
Bearing	B120052M	EHB120052M	AC GENERATOR	20032-2	ATR	ATR42-200
Brush	738466-6	EH738466-6	BRUSH BLOCK ASSEMBLY	782689-1 THRU -6	ATR-GIE Avions de Transport Regional	ATR42-200
Teflon Brush Block Pad	789285-1	EH789285-1	BRUSH BLOCK ASSEMBLY	782689-1 Thru -6	ATR-GIE Avions de Transport Regional	ATR42-200
Brush	RP607965	EHRP607965	STARTER GENERATOR	8260-121, 8260-123	ATR-GIE Avions de Transport Regional	ATR42-200
Magnetic Speed Pick-Up	SP-1	EHSP-1	STARTER GENERATOR	23080-SERIES, 23081-SERIES, 23085-SERIES, 23095-SERIES, 8260-121, 8160-121, 200SG-SERIES, 300SG SERIES, 400SG-SERIES	ATR-GIE Avions de Transport Regional	ATR42-200
Connector	9DBA30H08-03PN	9DBA30H08-03PNEH	STARTER GENERATOR	8260-121, 8260-123	ATR	ATR42-200
Bearing	B320050L	EHB320050L	STARTER GENERATOR	8260-121, 8260-123	ATR	ATR42-200
Bearing	B120252M	EHB120252M	AC GENERATOR	20032-2	ATR	ATR42-200
Lamp	29210A2140055X	29210A2140055XH	STROBE LIGHT ASSEMBLY	292-12	ATR	ATR42-200
Lamp	R25-2-2013A	R25-2-2013AEH	ANTI-COLLISION LIGHT ASSEMBLY	R25-1M2CW	ATR	ATR42-200
Lock Washer	P723526	P723526EH	STARTER GENERATOR	8160-121, 8260-121, 8260-123	ATR	ATR42-200
Lining	P714154-1	P714154-1EH	STARTER GENERATOR	8160-121, 8260-121, 8260-123	ATR-GIE Avions de Transport Regional	ATR42-200
Gasket	R25-2-2007-1	R25-2-2007-1EH	ANTI-COLLISION LIGHT ASSEMBLY	R25-1M2( )	ATR-GIE Avions de Transport Regional	ATR42-200
Torque Shaft	P603630	P603630EH	STARTER GENERATOR	8260-121, 8260-123	ATR-GIE Avions de Transport Regional	ATR42-200
Lining	P714154-1	P714154-1EH	STARTER GENERATOR	8160-121, 8260-121, 8260-123	ATR-GIE Avions de Transport Regional	ATR42-201
Lining	P714154-1	P714154-1EH	STARTER GENERATOR	8160-121, 8260-121, 8260-123	ATR-GIE Avions de Transport Regional	ATR42-202
Bearing	B320050L	EHB320050L	STARTER GENERATOR	8260-121, 8260-123	ATR	ATR42-300

Bearing	B120052M	EHB120052M	AC GENERATOR	20032-2	ATR	ATR42-300
Brush	738466-6	EH738466-6	BRUSH BLOCK ASSEMBLY	782689-1 THRU -6	ATR-GIE Avions de Transport Regional	ATR42-300
Teflon Brush Block Pad	789285-1	EH789285-1	BRUSH BLOCK ASSEMBLY	782689-1 Thru -6	ATR-GIE Avions de Transport Regional	ATR42-300
Brush	RP607965	EHRP607965	STARTER GENERATOR	8260-121, 8260-123	ATR-GIE Avions de Transport Regional	ATR42-300
Magnetic Speed Pick-Up	SP-1	EHSP-1	STARTER GENERATOR	23080-SERIES, 23081-SERIES, 23085-SERIES, 23095-SERIES, 8260-121, 8160-121, 200SG-SERIES, 300SG SERIES, 400SG-SERIES	ATR-GIE Avions de Transport Regional	ATR42-300
Connector	9DBA30H08-03PN	9DBA30H08-03PNEH	STARTER GENERATOR	8260-121, 8260-123	ATR	ATR42-300
Bearing	B320050L	EHB320050L	STARTER GENERATOR	8260-121, 8260-123	ATR	ATR42-300
Bearing	B120052M	EHB120052M	AC GENERATOR	20032-2	ATR	ATR42-300
Lamp	29210A2140055X	29210A2140055XH	STROBE LIGHT ASSEMBLY	292-12	ATR	ATR42-300
Lamp	R25-2-2013A	R25-2-2013AEH	ANTI-COLLISION LIGHT ASSEMBLY	R25-1M2CW	ATR	ATR42-300
Lock Washer	P723526	P723526EH	STARTER GENERATOR	8160-121, 8260-121, 8260-123	ATR	ATR42-300
Lining	P714154-1	P714154-1EH	STARTER GENERATOR	8160-121, 8260-121, 8260-123	ATR-GIE Avions de Transport Regional	ATR42-300
Gasket	R25-2-2007-1	R25-2-2007-1EH	ANTI-COLLISION LIGHT ASSEMBLY	R25-1M2( )	ATR-GIE Avions de Transport Regional	ATR42-300
Torque Shaft	P603630	P603630EH	STARTER GENERATOR	8260-121, 8260-123	ATR-GIE Avions de Transport Regional	ATR42-300
Bearing	B320050L	EHB320050L	STARTER GENERATOR	8260-121, 8260-123	ATR	ATR42-320
Bearing	B120052M	EHB120052M	AC GENERATOR	20032-2	ATR	ATR42-320
Brush	738466-6	EH738466-6	BRUSH BLOCK ASSEMBLY	782689-1 THRU -6	ATR-GIE Avions de Transport Regional	ATR42-320
Teflon Brush Block Pad	789285-1	EH789285-1	BRUSH BLOCK ASSEMBLY	782689-1 Thru -6	ATR-GIE Avions de Transport Regional	ATR42-320
Brush	RP607965	EHRP607965	STARTER GENERATOR	8260-121, 8260-123	ATR-GIE Avions de Transport Regional	ATR42-320
Magnetic Speed Pick-Up	SP-1	EHSP-1	STARTER GENERATOR	23080-SERIES, 23081-SERIES, 23085-SERIES, 23095-SERIES, 8260-121, 8160-121, 200SG-SERIES, 300SG SERIES, 400SG-SERIES	ATR-GIE Avions de Transport Regional	ATR42-320
Connector	9DBA30H08-03PN	9DBA30H08-03PNEH	STARTER GENERATOR	8260-121, 8260-123	ATR	ATR42-320
Bearing	B320050L	EHB320050L	STARTER GENERATOR	8260-121, 8260-123	ATR	ATR42-320
Bearing	B120052M	EHB120052M	AC GENERATOR	20032-2	ATR	ATR42-320
Lamp	29210A2140055X	29210A2140055XH	STROBE LIGHT ASSEMBLY	292-12	ATR	ATR42-320
Lamp	R25-2-2013A	R25-2-2013AEH	ANTI-COLLISION LIGHT ASSEMBLY	R25-1M2CW	ATR	ATR42-320
Lock Washer	P723526	P723526EH	STARTER GENERATOR	8160-121, 8260-121, 8260-123	ATR	ATR42-320

Lining	P714154-1	P714154-1EH	STARTER GENERATOR	8160-121, 8260-121, 8260-123	ATR-GIE Avions de Transport Regional	ATR42-320
Gasket	R25-2-2007-1	R25-2-2007-1EH	ANTI-COLLISION LIGHT ASSEMBLY	R25-1M2( )	ATR-GIE Avions de Transport Regional	ATR42-320
Torque Shaft	P603630	P603630EH	STARTER GENERATOR	8260-121, 8260-123	ATR-GIE Avions de Transport Regional	ATR42-320
Bearing	B320050L	EHB320050L	STARTER GENERATOR	8260-121, 8260-123	ATR	ATR42-500
Bearing	B120052M	EHB120052M	AC GENERATOR	20032-2	ATR	ATR42-500
Brush	738466-6	EH738466-6	BRUSH BLOCK ASSEMBLY	782689-1 THRU -6	ATR-GIE Avions de Transport Regional	ATR42-500
Teflon Brush Block Pad	789285-1	EH789285-1	BRUSH BLOCK ASSEMBLY	782689-1 Thru -6	ATR-GIE Avions de Transport Regional	ATR42-500
Brush	RP607965	EHRP607965	STARTER GENERATOR	8260-121, 8260-123	ATR-GIE Avions de Transport Regional	ATR42-500
Magnetic Speed Pick-Up	SP-1	EHSP-1	STARTER GENERATOR	23080-SERIES, 23081-SERIES, 23085-SERIES, 23095-SERIES, 8260-121, 8160-121, 200SG-SERIES, 300SG SERIES, 400SG-SERIES	ATR-GIE Avions de Transport Regional	ATR42-500
Connector	9DBA30H08-03PN	9DBA30H08-03PNEH	STARTER GENERATOR	8260-121, 8260-123	ATR	ATR42-500
Bearing	B320050L	EHB320050L	STARTER GENERATOR	8260-121, 8260-123	ATR	ATR42-500
Bearing	B120052M	EHB120052M	AC GENERATOR	20032-2	ATR	ATR42-500
Lamp	29210A2140055X	29210A2140055XH	STROBE LIGHT ASSEMBLY	292-12	ATR	ATR42-500
Lamp	R25-2-2013A	R25-2-2013AEH	ANTI-COLLISION LIGHT ASSEMBLY	R25-1M2CW	ATR	ATR42-500
Lock Washer	P723526	P723526EH	STARTER GENERATOR	8160-121, 8260-121, 8260-123	ATR	ATR42-500
Lining	P714154-1	P714154-1EH	STARTER GENERATOR	8160-121, 8260-121, 8260-123	ATR-GIE Avions de Transport Regional	ATR42-500
Gasket	R25-2-2007-1	R25-2-2007-1EH	ANTI-COLLISION LIGHT ASSEMBLY	R25-1M2( )	ATR-GIE Avions de Transport Regional	ATR42-500
Torque Shaft	P603630	P603630EH	STARTER GENERATOR	8260-121, 8260-123	ATR-GIE Avions de Transport Regional	ATR42-500
Bearing	B320050L	EHB320050L	STARTER GENERATOR	8260-121, 8260-123	ATR	ATR72-101
Bearing	B120252M	EHB120252M	AC GENERATOR	20032-2	ATR	ATR72-101
Brush	738466-6	EH738466-6	BRUSH BLOCK ASSEMBLY	782689-1 THRU -6	ATR-GIE Avions de Transport Regional	ATR72-101
Brush	RP607965	EHRP607965	STARTER GENERATOR	8260-121, 8260-123	ATR-GIE Avions de Transport Regional	ATR72-101
Magnetic Speed Pick-Up	SP-1	EHSP-1	STARTER GENERATOR	23080-SERIES, 23081-SERIES, 23085-SERIES, 23095-SERIES, 8260-121, 8160-121, 200SG-SERIES, 300SG SERIES, 400SG-SERIES	ATR-GIE Avions de Transport Regional	ATR72-101
Connector	9DBA30H08-03PN	9DBA30H08-03PNEH	STARTER GENERATOR	8260-121, 8260-123	ATR	ATR72-101
Bearing	B320050L	EHB320050L	STARTER GENERATOR	8260-121, 8260-123	ATR	ATR72-101
Bearing	B120052M	EHB120052M	AC GENERATOR	20032-2	ATR	ATR72-101

Lamp	29210A2140055X	29210A2140055XH	STROBE LIGHT ASSEMBLY	292-12	ATR	ATR72-101
Lamp	R25-2-2013A	R25-2-2013AEH	ANTI-COLLISION LIGHT ASSEMBLY	R25-1M2CW	ATR	ATR72-101
Lock Washer	P723526	P723526EH	STARTER GENERATOR	8160-121, 8260-121, 8260-123	ATR	ATR72-101
Gasket	R25-2-2007-1	R25-2-2007-1EH	ANTI-COLLISION LIGHT ASSEMBLY	R25-1M2( )	ATR-GIE Avions de Transport Regional	ATR72-101
Torque Shaft	P603630	P603630EH	STARTER GENERATOR	8260-121, 8260-123	ATR-GIE Avions de Transport Regional	ATR72-101
Bearing	B320050L	EHB320050L	STARTER GENERATOR	8260-121, 8260-123	ATR	ATR72-102
Bearing	B120252M	EHB120252M	AC GENERATOR	20032-2	ATR	ATR72-102
Brush	738466-6	EH738466-6	BRUSH BLOCK ASSEMBLY	782689-1 THRU -6	ATR-GIE Avions de Transport Regional	ATR72-102
Brush	RP607965	EHRP607965	STARTER GENERATOR	8260-121, 8260-123	ATR-GIE Avions de Transport Regional	ATR72-102
Magnetic Speed Pick-Up	SP-1	EHSP-1	STARTER GENERATOR	23080-SERIES, 23081-SERIES, 23085-SERIES, 23095-SERIES, 8260-121, 8160-121, 200SG-SERIES, 300SG SERIES, 400SG-SERIES	ATR-GIE Avions de Transport Regional	ATR72-102
Connector	9DBA30H08-03PN	9DBA30H08-03PNEH	STARTER GENERATOR	8260-121, 8260-123	ATR	ATR72-102
Bearing	B320050L	EHB320050L	STARTER GENERATOR	8260-121, 8260-123	ATR	ATR72-102
Bearing	B120052M	EHB120052M	AC GENERATOR	20032-2	ATR	ATR72-102
Lamp	29210A2140055X	29210A2140055XH	STROBE LIGHT ASSEMBLY	292-12	ATR	ATR72-102
Lamp	R25-2-2013A	R25-2-2013AEH	ANTI-COLLISION LIGHT ASSEMBLY	R25-1M2CW	ATR	ATR72-102
Lock Washer	P723526	P723526EH	STARTER GENERATOR	8160-121, 8260-121, 8260-123	ATR	ATR72-102
Gasket	R25-2-2007-1	R25-2-2007-1EH	ANTI-COLLISION LIGHT ASSEMBLY	R25-1M2( )	ATR-GIE Avions de Transport Regional	ATR72-102
Torque Shaft	P603630	P603630EH	STARTER GENERATOR	8260-121, 8260-123	ATR-GIE Avions de Transport Regional	ATR72-102
Bearing	B320050L	EHB320050L	STARTER GENERATOR	8260-121, 8260-123	ATR	ATR72-201
Bearing	B120052M	EHB120052M	AC GENERATOR	20032-2	ATR	ATR72-201
Brush	738466-6	EH738466-6	BRUSH BLOCK ASSEMBLY	782689-1 THRU -6	ATR-GIE Avions de Transport Regional	ATR72-201
Brush	RP607965	EHRP607965	STARTER GENERATOR	8260-121, 8260-123	ATR-GIE Avions de Transport Regional	ATR72-201
Magnetic Speed Pick-Up	SP-1	EHSP-1	STARTER GENERATOR	23080-SERIES, 23081-SERIES, 23085-SERIES, 23095-SERIES, 8260-121, 8160-121, 200SG-SERIES, 300SG SERIES, 400SG-SERIES	ATR-GIE Avions de Transport Regional	ATR72-201
Connector	9DBA30H08-03PN	9DBA30H08-03PNEH	STARTER GENERATOR	8260-121, 8260-123	ATR	ATR72-201
Bearing	B320050L	EHB320050L	STARTER GENERATOR	8260-121, 8260-123	ATR	ATR72-201
Bearing	B120252M	EHB120252M	AC GENERATOR	20032-2	ATR	ATR72-201
Lamp	29210A2140055X	29210A2140055XH	STROBE LIGHT ASSEMBLY	292-12	ATR	ATR72-201

Lamp	R25-2-2013A	R25-2-2013AEH	ANTI-COLLISION LIGHT ASSEMBLY	R25-1M2CW	ATR	ATR72-201
Lock Washer	P723526	P723526EH	STARTER GENERATOR	8160-121, 8260-121, 8260-123	ATR	ATR72-201
Gasket	R25-2-2007-1	R25-2-2007-1EH	ANTI-COLLISION LIGHT ASSEMBLY	R25-1M2( )	ATR–GIE Avions de Transport Regional	ATR72-201
Torque Shaft	P603630	P603630EH	STARTER GENERATOR	8260-121, 8260-123	ATR–GIE Avions de Transport Regional	ATR72-201
Bearing	B320050L	EHB320050L	STARTER GENERATOR	8260-121, 8260-123	ATR	ATR72-202
Bearing	B120052M	EHB120052M	AC GENERATOR	20032-2	ATR	ATR72-202
Brush	738466-6	EH738466-6	BRUSH BLOCK ASSEMBLY	782689-1 THRU -6	ATR–GIE Avions de Transport Regional	ATR72-202
Brush	RP607965	EHRP607965	STARTER GENERATOR	8260-121, 8260-123	ATR–GIE Avions de Transport Regional	ATR72-202
Magnetic Speed Pick-Up	SP-1	EHSP-1	STARTER GENERATOR	23080-SERIES, 23081-SERIES, 23085-SERIES, 23095-SERIES, 8260-121, 8160-121, 200SG-SERIES, 300SG SERIES, 400SG-SERIES	ATR–GIE Avions de Transport Regional	ATR72-202
Connector	9DBA30H08-03PN	9DBA30H08-03PNEH	STARTER GENERATOR	8260-121, 8260-123	ATR	ATR72-202
Bearing	B320050L	EHB320050L	STARTER GENERATOR	8260-121, 8260-123	ATR	ATR72-202
Bearing	B120052M	EHB120052M	AC GENERATOR	20032-2	ATR	ATR72-202
Lamp	29210A2140055X	29210A2140055XH	STROBE LIGHT ASSEMBLY	292-12	ATR	ATR72-202
Lamp	R25-2-2013A	R25-2-2013AEH	ANTI-COLLISION LIGHT ASSEMBLY	R25-1M2CW	ATR	ATR72-202
Lock Washer	P723526	P723526EH	STARTER GENERATOR	8160-121, 8260-121, 8260-123	ATR	ATR72-202
Lining	P714154-1	P714154-1EH	STARTER GENERATOR	8160-121, 8260-121, 8260-123	ATR–GIE Avions de Transport Regional	ATR72-202
Gasket	R25-2-2007-1	R25-2-2007-1EH	ANTI-COLLISION LIGHT ASSEMBLY	R25-1M2( )	ATR–GIE Avions de Transport Regional	ATR72-202
Torque Shaft	P603630	P603630EH	STARTER GENERATOR	8260-121, 8260-123	ATR–GIE Avions de Transport Regional	ATR72-202
Bearing	B320050L	EHB320050L	STARTER GENERATOR	8260-121, 8260-123	ATR	ATR72-211
Bearing	B120052M	EHB120052M	AC GENERATOR	20032-2	ATR	ATR72-211
Brush	738466-6	EH738466-6	BRUSH BLOCK ASSEMBLY	782689-1 THRU -6	ATR–GIE Avions de Transport Regional	ATR72-211
Brush	RP607965	EHRP607965	STARTER GENERATOR	8260-121, 8260-123	ATR–GIE Avions de Transport Regional	ATR72-211
Magnetic Speed Pick-Up	SP-1	EHSP-1	STARTER GENERATOR	23080-SERIES, 23081-SERIES, 23085-SERIES, 23095-SERIES, 8260-121, 8160-121, 200SG-SERIES, 300SG SERIES, 400SG-SERIES	ATR–GIE Avions de Transport Regional	ATR72-211
Connector	9DBA30H08-03PN	9DBA30H08-03PNEH	STARTER GENERATOR	8260-121, 8260-123	ATR	ATR72-211
Lamp	29210A2140055X	29210A2140055XH	STROBE LIGHT ASSEMBLY	292-12	ATR	ATR72-211
Lamp	R25-2-2013A	R25-2-2013AEH	ANTI-COLLISION LIGHT ASSEMBLY	R25-1M2CW	ATR	ATR72-211
Lock Washer	P723526	P723526EH	STARTER GENERATOR	8160-121, 8260-121, 8260-123	ATR	ATR72-211

Lining	P714154-1	P714154-1EH	STARTER GENERATOR	8160-121, 8260-121, 8260-123	ATR–GIE Avions de Transport Regional	ATR72-211
Gasket	R25-2-2007-1	R25-2-2007-1EH	ANTI-COLLISION LIGHT ASSEMBLY	R25-1M2( )	ATR–GIE Avions de Transport Regional	ATR72-211
Torque Shaft	P603630	P603630EH	STARTER GENERATOR	8260-121, 8260-123	ATR–GIE Avions de Transport Regional	ATR72-211
Bearing	B320050L	EHB320050L	STARTER GENERATOR	8260-121, 8260-123	ATR	ATR72-212
Bearing	B120052M	EHB120052M	AC GENERATOR	20032-2	ATR	ATR72-212
Brush	RP607965	EHRP607965	STARTER GENERATOR	8260-121, 8260-123	ATR–GIE Avions de Transport Regional	ATR72-212
Magnetic Speed Pick-Up	SP-1	EHSP-1	STARTER GENERATOR	23080-SERIES, 23081-SERIES, 23085-SERIES, 23095-SERIES, 8260-121, 8160-121, 200SG-SERIES, 300SG SERIES, 400SG-SERIES	ATR–GIE Avions de Transport Regional	ATR72-212
Connector	9DBA30H08-03PN	9DBA30H08-03PNEH	STARTER GENERATOR	8260-121, 8260-123	ATR	ATR72-212
Lamp	29210A2140055X	29210A2140055XH	STROBE LIGHT ASSEMBLY	292-12	ATR	ATR72-212
Lamp	R25-2-2013A	R25-2-2013AEH	ANTI-COLLISION LIGHT ASSEMBLY	R25-1M2CW	ATR	ATR72-212
Lock Washer	P723526	P723526EH	STARTER GENERATOR	8160-121, 8260-121, 8260-123	ATR	ATR72-212
Lining	P714154-1	P714154-1EH	STARTER GENERATOR	8160-121, 8260-121, 8260-123	ATR–GIE Avions de Transport Regional	ATR72-212
Gasket	R25-2-2007-1	R25-2-2007-1EH	ANTI-COLLISION LIGHT ASSEMBLY	R25-1M2( )	ATR–GIE Avions de Transport Regional	ATR72-212
Torque Shaft	P603630	P603630EH	STARTER GENERATOR	8260-121, 8260-123	ATR–GIE Avions de Transport Regional	ATR72-212
Bearing	B320050L	EHB320050L	STARTER GENERATOR	8260-121, 8260-123	ATR	ATR72-212A
Bearing	B120252M	EHB120252M	AC GENERATOR	20032-2	ATR	ATR72-212A
Brush	738466-6	EH738466-6	BRUSH BLOCK ASSEMBLY	782689-1 THRU -6	ATR–GIE Avions de Transport Regional	ATR72-212A
Brush	RP607965	EHRP607965	STARTER GENERATOR	8260-121, 8260-123	ATR–GIE Avions de Transport Regional	ATR72-212A
Magnetic Speed Pick-Up	SP-1	EHSP-1	STARTER GENERATOR	23080-SERIES, 23081-SERIES, 23085-SERIES, 23095-SERIES, 8260-121, 8160-121, 200SG-SERIES, 300SG SERIES, 400SG-SERIES	ATR–GIE Avions de Transport Regional	ATR72-212A
Lamp	29210A2140055X	29210A2140055XH	STROBE LIGHT ASSEMBLY	292-12	ATR	ATR72-212A
Lamp	R25-2-2013A	R25-2-2013AEH	ANTI-COLLISION LIGHT ASSEMBLY	R25-1M2CW	ATR	ATR72-212A
Lock Washer	P723526	P723526EH	STARTER GENERATOR	8160-121, 8260-121, 8260-123	ATR	ATR72-212A
Lining	P714154-1	P714154-1EH	STARTER GENERATOR	8160-121, 8260-121, 8260-123	ATR–GIE Avions de Transport Regional	ATR72-212A
Gasket	R25-2-2007-1	R25-2-2007-1EH	ANTI-COLLISION LIGHT ASSEMBLY	R25-1M2( )	ATR–GIE Avions de Transport Regional	ATR72-212A
Torque Shaft	P603630	P603630EH	STARTER GENERATOR	8260-121, 8260-123	ATR–GIE Avions de Transport Regional	ATR72-212A

Connector	9DBA30H08-03PN	9DBA30H08-03PNEH	STARTER GENERATOR	8260-121, 8260-123	ATR	ATR72-212-A
Lock Washer	P723526	P723526EH	STARTER GENERATOR	8160-121, 8260-121, 8260-123	ATR	Dornier Model 328-100
Lock Washer	P723526	P723526EH	STARTER GENERATOR	8160-121, 8260-121, 8260-123	ATR	Dornier Model 328-300