



Bell Application List

P: 705-742-9725

www.kadexaero.com

Contact:

Description	OEM PN	Seginus PN	NHA Description	NHA PN	Aircraft	Aircraft Model Number
Brush	420A21	EH420A21	BLOWER - BLOWER MOTOR	101-384004-1, M3436MB	Bell	206
Brush	420A20	EH420A20	BLOWER - BLOWER MOTOR	C175R-3A1, 60-384002-5, 60-384002-7, M4941Z-1A, C241-500B	Bell	206
Brush	23033-1141	EH23033-1141	STARTER GENERATOR	23032-020, 23032-022	Bell	206
Bearing	03-6010-18	EH03-6010-18	STARTER GENERATOR	23080-Series (001, 025-1, 005, 064, 013, 014, 002, 059, 031, 032)	Bell	212
Brush	30300-1413	EH30300-1413	STARTER GENERATOR	23085-Series (028, 029, 030, 031, 005)	Bell	212
Brush	30300-1285	EH30300-1285	STARTER GENERATOR	23048-016, 23046 Series, 23048 Series	Bell	212
Brush	R30300-1413	EHR30300-1413	STARTER GENERATOR	23085-Series (028, 029, 030, 031, 005)	Bell	212
Bearing	03-6010-18	EH03-6010-18	STARTER GENERATOR	23080-Series (001, 025-1, 005, 064, 013, 014, 002, 059, 031, 032)	Bell	212
Bearing	03-6009-23	EH03-6009-23	STARTER GENERATOR	23088-008	Bell Helicopter Textron Canada Ltd	222
Brush	23033-1141	EH23033-1141	STARTER GENERATOR	23032-020, 23032-022	Bell	222
Bearing	03-6009-23	EH03-6009-23	STARTER GENERATOR	23088-008	Bell	222
Bearing	150SG1052-1	EH150SG1052-1	STARTER GENERATOR	200SGL124Q, 200SGL123Q	Bell Helicopter Textron Canada Ltd	230
Bearing	150SG1052-10	EH150SG1052-10	STARTER GENERATOR	200SGL115Q-2, 200SGL144Q	Bell Helicopter Textron Canada Ltd	230
Bearing	150SG1052-1	EH150SG1052-1	STARTER GENERATOR	200SGL124Q, 200SGL123Q	Bell	230
Bearing	150SG1052-10	EH150SG1052-10	STARTER GENERATOR	200SGL115Q-2, 200SGL144Q	Bell	230
Brushes	200SGL1009-10X2	200SGL1009-10X2EH	STARTER GENERATOR	200SGL111Q, 200SGL117Q, 200SGL129Q, 200SGL130Q, 200SGL132Q-4, 200SGL144Q, 200SGL147Q-3, 200SGL111Q-3, 200SGL118Q, 200SGL129Q (4), 200SGL132Q, 200SGL132Q-5, 200SGL147Q, 200SGL151Q, 200SGL115Q, 200SGL124Q, 200SGL129Q (8), 200SGL132Q-3, 200SGL142Q, 200SGL147Q-2, 200SGL153Q	Bell	230
Bearing	03-6009-23	EH03-6009-23	STARTER GENERATOR	23088-008	Bell Helicopter Textron Canada Ltd	407
Brush	23033-1141	EH23033-1141	STARTER GENERATOR	23032-020, 23032-022	Bell	407
Bearing	150SG1052-1	EH150SG1052-1	STARTER GENERATOR	200SGL124Q, 200SGL123Q	Bell Helicopter Textron Canada Ltd	407
Bearing	150SG1052-10	EH150SG1052-10	STARTER GENERATOR	200SGL115Q-2, 200SGL144Q	Bell Helicopter Textron Canada Ltd	407
Bearing	150SG1052-1	EH150SG1052-1	STARTER GENERATOR	200SGL124Q, 200SGL123Q	Bell	407
Bearing	150SG1052-10	EH150SG1052-10	STARTER GENERATOR	200SGL115Q-2, 200SGL144Q	Bell	407
Bearing	03-6009-23	EH03-6009-23	STARTER GENERATOR	23088-008	Bell	407
Bearing	03-6010-18	EH03-6010-18	STARTER GENERATOR	23080-Series (001, 025-1, 005, 064, 013, 014, 002, 059, 031, 032)	Bell	412
Bearing	400SG1052-13	EH400SG1052-13	STARTER GENERATOR	400SG MODEL LIST	Bell	412
Brush	30300-1413	EH30300-1413	STARTER GENERATOR	23085-Series (028, 029, 030, 031, 005)	Bell	412
Brush	30300-1285	EH30300-1285	STARTER GENERATOR	23048-016, 23046 Series, 23048 Series	Bell	412
Brush	R30300-1413	EHR30300-1413	STARTER GENERATOR	23085-Series (028, 029, 030, 031, 005)	Bell	412

Magnetic Speed Pick-Up	SP-1	EHSP-1	STARTER GENERATOR	23080-SERIES, 23081-SERIES, 23085-SERIES, 23095-SERIES, 8260-121, 8160-121, 200SG-SERIES, 300SG SERIES, 400SG-SERIES	Bell	412
Bearing	03-6010-18	EH03-6010-18	STARTER GENERATOR	23080-Series (001, 025-1, 005, 064, 013, 014, 002, 059, 031, 032)	Bell	412
Bearing	03-6009-23	EH03-6009-23	STARTER GENERATOR	23088-008	Bell Helicopter Textron Canada Ltd	430
Bearing	150SG1052-1	EH150SG1052-1	STARTER GENERATOR	200SGL124Q, 200SGL123Q	Bell Helicopter Textron Canada Ltd	430
Bearing	150SG1052-10	EH150SG1052-10	STARTER GENERATOR	200SGL115Q-2, 200SGL144Q	Bell Helicopter Textron Canada Ltd	430
Bearing	150SG1052-1	EH150SG1052-1	STARTER GENERATOR	200SGL124Q, 200SGL123Q	Bell	430
Bearing	150SG1052-10	EH150SG1052-10	STARTER GENERATOR	200SGL115Q-2, 200SGL144Q	Bell	430
Bearing	03-6009-23	EH03-6009-23	STARTER GENERATOR	23088-008	Bell	430
Brushes	200SGL1009-10X2	200SGL1009-10X2EH	STARTER GENERATOR	200SGL111Q, 200SGL117Q, 200SGL129Q, 200SGL130Q, 200SGL132Q-4, 200SGL144Q, 200SGL147Q-3, 200SGL111Q-3, 200SGL118Q, 200SGL129Q (4), 200SGL132Q, 200SGL132Q-5, 200SGL147Q, 200SGL151Q, 200SGL115Q, 200SGL124Q, 200SGL129Q (8), 200SGL132Q-3, 200SGL142Q, 200SGL147Q-2, 200SGL153Q	Bell	430
Brush	30300-1413	EH30300-1413	STARTER GENERATOR	23085-Series (028, 029, 030, 031, 005)	Bell	204B
Brush	R30300-1413	EHR30300-1413	STARTER GENERATOR	23085-Series (028, 029, 030, 031, 005)	Bell	204B
Brush	30300-1413	EH30300-1413	STARTER GENERATOR	23085-Series (028, 029, 030, 031, 005)	Bell	205A
Brush	R30300-1413	EHR30300-1413	STARTER GENERATOR	23085-Series (028, 029, 030, 031, 005)	Bell	205A
Brush	30300-1413	EH30300-1413	STARTER GENERATOR	23085-Series (028, 029, 030, 031, 005)	Bell	205A-1
Brush	R30300-1413	EHR30300-1413	STARTER GENERATOR	23085-Series (028, 029, 030, 031, 005)	Bell	205A-1
Brush	30300-1413	EH30300-1413	STARTER GENERATOR	23085-Series (028, 029, 030, 031, 005)	Bell	205B
Brush	R30300-1413	EHR30300-1413	STARTER GENERATOR	23085-Series (028, 029, 030, 031, 005)	Bell	205B
Bearing	03-6009-23	EH03-6009-23	STARTER GENERATOR	23088-008	Bell Helicopter Textron Canada Ltd	206A
Brush	420A21	EH420A21	BLOWER - BLOWER MOTOR	101-384004-1, M3436MB	Bell	206A
Brush	420A20	EH420A20	BLOWER - BLOWER MOTOR	C175R-3A1, 60-384002-5, 60-384002-7, M4941Z-1A, C241-500B	Bell	206A
Brush	23033-1141	EH23033-1141	STARTER GENERATOR	23032-020, 23032-022	Bell	206A
Bearing	03-6009-23	EH03-6009-23	STARTER GENERATOR	23088-008	Bell	206A
Brushes	150SG1009-5	150SG1009-5EH	STARTER GENERATOR	150SG111Q, 150SG116Q, 150SG117Q-4, 150SG120Q, 150SG125Q-2, 150SG114Q, 150SG117Q, 150SG118Q, 150SG122Q, 150SG144Q, 150SG115Q, 150SF117Q-3, 150SG119Q, 150SG125Q, 160SG137Q-2, 160SG139Q-2, 160SG140Q, 160SG141Q	Bell	206A
Drive Shaft Assembly	150SG1103-2	150SG1103-2EH	STARTER GENERATOR	150SG115Q, 150SG117Q, 150SG123Q, 150SG144Q, 150SG125Q-2, 150SG117Q-3, 150SG117Q-4,	Bell	206A
Brush	420A21	EH420A21	BLOWER - BLOWER MOTOR	101-384004-1, M3436MB	Bell	206A-1
Brush	23033-1141	EH23033-1141	STARTER GENERATOR	23032-020, 23032-022	Bell	206A-1 (OH-58A)
Bearing	03-6009-23	EH03-6009-23	STARTER GENERATOR	23088-008	Bell Helicopter Textron Canada Ltd	206B
Bearing	150SG1052-B	EH150SG1052-B	STARTER GENERATOR	200SG MODEL LIST	Bell	206B
Brush	420A21	EH420A21	BLOWER - BLOWER MOTOR	101-384004-1, M3436MB	Bell	206B
Brush	420A20	EH420A20	BLOWER - BLOWER MOTOR	C175R-3A1, 60-384002-5, 60-384002-7, M4941Z-1A, C241-500B	Bell	206B

Brush	23033-1141	EH23033-1141	STARTER GENERATOR	23032-020, 23032-022	Bell	206B
Bearing	03-6009-18	EH03-6009-18	STARTER GENERATOR	23085-Series (028, 029, 030, 031, 005)	Bell Helicopter Textron Canada Ltd	206B
Bearing	03-6009-18	EH03-6009-18	STARTER GENERATOR	23085-Series (028, 029, 030, 031, 005)	Bell	206B
Bearing	03-6009-23	EH03-6009-23	STARTER GENERATOR	23088-008	Bell	206B
Brushes	150SG1009-5	150SG1009-5EH	STARTER GENERATOR	150SG111Q, 150SG116Q, 150SG117Q-4, 150SG120Q, 150SG125Q-2, 150SG114Q, 150SG117Q, 150SG118Q, 150SG122Q, 150SG144Q, 150SG115Q, 150SF117Q-3, 150SG119Q, 150SG125Q, 160SG137Q-2, 160SG139Q-2, 160SG140Q, 160SG141Q	Bell	206B
Drive Shaft Assembly	150SG1103-2	150SG1103-2EH	STARTER GENERATOR	150SG115Q, 150SG117Q, 150SG123Q, 150SG144Q, 150SG125Q-2, 150SG117Q-3, 150SG117Q-4,	Bell	206B
Brush	420A21	EH420A21	BLOWER - BLOWER MOTOR	101-384004-1, M3436MB	Bell	206B1
Brush	23033-1141	EH23033-1141	STARTER GENERATOR	23032-020, 23032-022	Bell	206B-1
Brush	420A20	EH420A20	BLOWER - BLOWER MOTOR	C175R-3A1, 60-384002-5, 60-384002-7, M4941Z-1A, C241-500B	Bell	206-B1
Bearing	150SG1052-B	EH150SG1052-B	STARTER GENERATOR	200SG MODEL LIST	Bell	206L
Brush	420A21	EH420A21	BLOWER - BLOWER MOTOR	101-384004-1, M3436MB	Bell	206L
Brush	420A20	EH420A20	BLOWER - BLOWER MOTOR	C175R-3A1, 60-384002-5, 60-384002-7, M4941Z-1A, C241-500B	Bell	206L
Brush	23033-1141	EH23033-1141	STARTER GENERATOR	23032-020, 23032-022	Bell	206L
Brushes	150SG1009-5	150SG1009-5EH	STARTER GENERATOR	150SG111Q, 150SG116Q, 150SG117Q-4, 150SG120Q, 150SG125Q-2, 150SG114Q, 150SG117Q, 150SG118Q, 150SG122Q, 150SG144Q, 150SG115Q, 150SF117Q-3, 150SG119Q, 150SG125Q, 160SG137Q-2, 160SG139Q-2, 160SG140Q, 160SG141Q	Bell	206L
Drive Shaft Assembly	150SG1103-2	150SG1103-2EH	STARTER GENERATOR	150SG115Q, 150SG117Q, 150SG123Q, 150SG144Q, 150SG125Q-2, 150SG117Q-3, 150SG117Q-4,	Bell	206L
Bearing	03-6009-23	EH03-6009-23	STARTER GENERATOR	23088-008	Bell Helicopter Textron Canada Ltd	206L-1
Bearing	150SG1052-B	EH150SG1052-B	STARTER GENERATOR	200SG MODEL LIST	Bell	206L-1
Brush	420A21	EH420A21	BLOWER - BLOWER MOTOR	101-384004-1, M3436MB	Bell	206L-1
Brush	420A20	EH420A20	BLOWER - BLOWER MOTOR	C175R-3A1, 60-384002-5, 60-384002-7, M4941Z-1A, C241-500B	Bell	206L-1
Brush	23033-1141	EH23033-1141	STARTER GENERATOR	23032-020, 23032-022	Bell	206L-1
Bearing	150SG1052-1	EH150SG1052-1	STARTER GENERATOR	200SGL124Q, 200SGL123Q	Bell Helicopter Textron Canada Ltd	206L-1
Bearing	150SG1052-10	EH150SG1052-10	STARTER GENERATOR	200SGL115Q-2, 200SGL144Q	Bell Helicopter Textron Canada Ltd	206L-1
Bearing	150SG1052-1	EH150SG1052-1	STARTER GENERATOR	200SGL124Q, 200SGL123Q	Bell	206L-1
Bearing	150SG1052-10	EH150SG1052-10	STARTER GENERATOR	200SGL115Q-2, 200SGL144Q	Bell	206L-1
Bearing	03-6009-23	EH03-6009-23	STARTER GENERATOR	23088-008	Bell	206L-1
Brushes	150SG1009-5	150SG1009-5EH	STARTER GENERATOR	150SG111Q, 150SG116Q, 150SG117Q-4, 150SG120Q, 150SG125Q-2, 150SG114Q, 150SG117Q, 150SG118Q, 150SG122Q, 150SG144Q, 150SG115Q, 150SF117Q-3, 150SG119Q, 150SG125Q, 160SG137Q-2, 160SG139Q-2, 160SG140Q, 160SG141Q	Bell	206L-1

Brushes	2005GL1009-3	2005GL1009-3EH	STARTER GENERATOR	2005GL111Q, 2005GL118Q, 2005GL129Q, 2005GL129Q (5), 2005GL142Q, 2005GL115Q, 2005GL119Q, 2005GL129Q (1), 2005GL130Q, 2005GL147Q, 2005GL115Q-2, 2005GL119Q-2, 2005GL129Q (3), 2005GL131Q	Bell	206L-1
Brushes	2005GL1009-7	2005GL1009-7EH	STARTER GENERATOR	2005GL111Q, 2005GL118Q	Bell	206L-1
Brushes	2005GL1009-10X2	2005GL1009-10X2EH	STARTER GENERATOR	2005GL111Q, 2005GL117Q, 2005GL129Q, 2005GL130Q, 2005GL132Q-4, 2005GL144Q, 2005GL147Q-3, 2005GL111Q-3, 2005GL118Q, 2005GL129Q (4), 2005GL132Q, 2005GL132Q-5, 2005GL147Q, 2005GL151Q, 2005GL115Q, 2005GL124Q, 2005GL129Q (8), 2005GL132Q-3, 2005GL142Q, 2005GL147Q-2, 2005GL153Q	Bell	206L-1
Bearing	03-6009-23	EH03-6009-23	STARTER GENERATOR	23088-008	Bell Helicopter Textron Canada Ltd	206L-3
Brush	420A21	EH420A21	BLOWER - BLOWER MOTOR	101-384004-1, M3436MB	Bell	206L-3
Brush	420A20	EH420A20	BLOWER - BLOWER MOTOR	C175R-3A1, 60-384002-5, 60-384002-7, M4941Z-1A, C241-500B	Bell	206L-3
Brush	23033-1141	EH23033-1141	STARTER GENERATOR	23032-020, 23032-022	Bell	206L-3
Bearing	150SG1052-1	EH150SG1052-1	STARTER GENERATOR	2005GL124Q, 2005GL123Q	Bell Helicopter Textron Canada Ltd	206L-3
Bearing	150SG1052-10	EH150SG1052-10	STARTER GENERATOR	2005GL115Q-2, 2005GL144Q	Bell Helicopter Textron Canada Ltd	206L-3
Bearing	150SG1052-1	EH150SG1052-1	STARTER GENERATOR	2005GL124Q, 2005GL123Q	Bell	206L-3
Bearing	150SG1052-10	EH150SG1052-10	STARTER GENERATOR	2005GL115Q-2, 2005GL144Q	Bell	206L-3
Bearing	03-6009-23	EH03-6009-23	STARTER GENERATOR	23088-008	Bell	206L-3
Brushes	2005GL1009-10X2	2005GL1009-10X2EH	STARTER GENERATOR	2005GL111Q, 2005GL117Q, 2005GL129Q, 2005GL130Q, 2005GL132Q-4, 2005GL144Q, 2005GL147Q-3, 2005GL111Q-3, 2005GL118Q, 2005GL129Q (4), 2005GL132Q, 2005GL132Q-5, 2005GL147Q, 2005GL151Q, 2005GL115Q, 2005GL124Q, 2005GL129Q (8), 2005GL132Q-3, 2005GL142Q, 2005GL147Q-2, 2005GL153Q	Bell	206L-3
Bearing	03-6009-23	EH03-6009-23	STARTER GENERATOR	23088-008	Bell Helicopter Textron Canada Ltd	206L-4
Brush	23033-1141	EH23033-1141	STARTER GENERATOR	23032-020, 23032-022	Bell	206L-4
Bearing	03-6009-23	EH03-6009-23	STARTER GENERATOR	23088-008	Bell	206L-4
Bearing	03-6009-23	EH03-6009-23	STARTER GENERATOR	23088-008	Bell	206L-4
Brush	420A21	EH420A21	BLOWER - BLOWER MOTOR	101-384004-1, M3436MB	Bell	206L-4
Brush	420A20	EH420A20	BLOWER - BLOWER MOTOR	C175R-3A1, 60-384002-5, 60-384002-7, M4941Z-1A, C241-500B	Bell	206L-4
Bearing	03-6009-23	EH03-6009-23	STARTER GENERATOR	23088-008	Bell Helicopter Textron Canada Ltd	222B
Brush	23033-1141	EH23033-1141	STARTER GENERATOR	23032-020, 23032-022	Bell	222B
Bearing	03-6009-18	EH03-6009-18	STARTER GENERATOR	23085-Series (028, 029, 030, 031, 005)	Bell Helicopter Textron Canada Ltd Division of Textron Canada	222B
Bearing	03-6009-18	EH03-6009-18	STARTER GENERATOR	23085-Series (028, 029, 030, 031, 005)	Bell	222B
Bearing	03-6009-23	EH03-6009-23	STARTER GENERATOR	23088-008	Bell	222B
Brush	23033-1141	EH23033-1141	STARTER GENERATOR	23032-020, 23032-022	Bell	222U
Bearing	03-6009-18	EH03-6009-18	STARTER GENERATOR	23085-Series (028, 029, 030, 031, 005)	Bell Helicopter Textron Canada Ltd	222U

Bearing	03-6009-18	EH03-6009-18	STARTER GENERATOR	23085-Series (028, 029, 030, 031, 005)	Bell	222U
Brush	30300-1285	EH30300-1285	STARTER GENERATOR	23048-016, 23046 Series, 23048 Series	Bell	412CF
Magnetic Speed Pick-Up	SP-1	EHSP-1	STARTER GENERATOR	23080-SERIES, 23081-SERIES, 23085-SERIES, 23095-SERIES, 8260-121, 8160-121, 200SG-SERIES, 300SG SERIES, 400SG-SERIES	Bell	412CF
Brush	30300-1285	EH30300-1285	STARTER GENERATOR	23048-016, 23046 Series, 23048 Series	Bell	412EP
Magnetic Speed Pick-Up	SP-1	EHSP-1	STARTER GENERATOR	23080-SERIES, 23081-SERIES, 23085-SERIES, 23095-SERIES, 8260-121, 8160-121, 200SG-SERIES, 300SG SERIES, 400SG-SERIES	Bell	412EP