



Bombardier Application List

P: 705-742-9725

www.kadexaero.com

Contact:



Descrtiption	OEM PN	Seginus PN	NHA Description	NHA PN	Aircraft	Aircraft Model Number
Bearing	400SG1052-13	EH400SG1052-13	STARTER GENERATOR	400SG MODEL LIST	Bombardier	CL-215-1A10
Brush	738466-6	EH738466-6	BRUSH BLOCK ASSEMBLY	782689-1 THRU -6	Bombardier	CL-215-6B11 (C1-215T Variant)
Teflon Brush Block Pad	789285-1	EH789285-1	BRUSH BLOCK ASSEMBLY	782689-1 Thru -6	Bombardier	CL-215-6B11 (CL215T Variant)
Brush	738466-6	EH738466-6	BRUSH BLOCK ASSEMBLY	782689-1 THRU -6	Bombardier	CL-215-6B11 (CL-415 Variant)
Teflon Brush Block Pad	789285-1	EH789285-1	BRUSH BLOCK ASSEMBLY	782689-1 Thru -6	Bombardier	CL-215-6B11 (CL415T Variant)
Passenger Door Wheel Support Bearing	601R38371-9	601R38371-9EH	Support	CC670-38624-3	Bombardier	CL-600-2515 (Regional Series 705)
Immersion Heater	200-0368-01	200-0368-01EH	COFFEE BREWER	1448, 1448-1, 1448-4	Bombardier	CL-600-2B19 (Regional Jet Series 100)
Heater Assembly	3575-1251-05	3575-1251-05EH	HEATER ASSEMBLY	3510-0039-01/03	Bombardier	CL-600-2B19 (Regional Jet Series 100)
Passenger Door Wheel Support Bearing	601R38371-9	601R38371-9EH	Support	CC670-38624-3	Bombardier	CL-600-2B19 (Regional Jet Series 100)
Floor Panel Fitting	21759-52	21759-52EH	CRJ200, 700, & 900 AIRCRAFT	21759-52	Bombardier	CL-600-2B19 (Regional Jet Series 100)
Floor Panel Fitting	21759-52	21759-52EH	CRJ200, 700, & 900 AIRCRAFT	21759-52	Bombardier	CL-600-2B19 (Regional Jet Series 400)
Immersion Heater	200-0368-01	200-0368-01EH	COFFEE BREWER	1448, 1448-1, 1448-4	Bombardier	CL-600-2B19 (Regional Jet Series 440)
Heater Assembly	3575-1251-05	3575-1251-05EH	HEATER ASSEMBLY	3510-0039-01/03	Bombardier	CL-600-2B19 (Regional Jet Series 440)
Passenger Door Wheel Support Bearing	601R38371-9	601R38371-9EH	Support	CC670-38624-3	Bombardier	CL-600-2B19 (Regional Jet Series 440)
Immersion Heater	200-0368-01	200-0368-01EH	COFFEE BREWER	1448, 1448-1, 1448-4	Bombardier	CL-600-2C10 (Regional Jet Series 700)
Heater Assembly	3575-1251-05	3575-1251-05EH	HEATER ASSEMBLY	3510-0039-01/03	Bombardier	CL-600-2C10 (Regional Jet Series 700)
Floor Panel Fitting	21759-52	21759-52EH	CRJ200, 700, & 900 AIRCRAFT	21759-52	Bombardier	CL-600-2C10 (Regional Jet Series 700)
Immersion Heater	200-0368-01	200-0368-01EH	COFFEE BREWER	1448, 1448-1, 1448-4	Bombardier	CL-600-2C10 (Regional Jet Series 701)

Heater Assembly	3575-1251-05	3575-1251-05EH	HEATER ASSEMBLY	3510-0039-01/03	Bombardier	CL-600-2C10 (Regional Jet Series 701)
Floor Panel Fitting	21759-52	21759-52EH	CRJ200, 700, & 900 AIRCRAFT	21759-52	Bombardier	CL-600-2C10 (Regional Jet Series 701)
Immersion Heater	200-0368-01	200-0368-01EH	COFFEE BREWER	1448, 1448-1, 1448-4	Bombardier	CL-600-2C10 (Regional Jet Series 702)
Heater Assembly	3575-1251-05	3575-1251-05EH	HEATER ASSEMBLY	3510-0039-01/03	Bombardier	CL-600-2C10 (Regional Jet Series 702)
Floor Panel Fitting	21759-52	21759-52EH	CRJ200, 700, & 900 AIRCRAFT	21759-52	Bombardier	CL-600-2C10 (Regional Jet Series 702)
Passenger Door Wheel Support Bearing	601R38371-9	601R38371-9EH	Support	CC670-38624-3	Bombardier	CL-600-2C10 (Regional Series 700)
Passenger Door Wheel Support Bearing	601R38371-9	601R38371-9EH	Support	CC670-38624-3	Bombardier	CL-600-2C10 (Regional Series 701)
Passenger Door Wheel Support Bearing	601R38371-9	601R38371-9EH	Support	CC670-38624-3	Bombardier	CL-600-2C10 (Regional Series 702)
Immersion Heater	200-0368-01	200-0368-01EH	COFFEE BREWER	1448, 1448-1, 1448-4	Bombardier	CL-600-2D15 (Regional Jet Series 705)
Heater Assembly	3575-1251-05	3575-1251-05EH	HEATER ASSEMBLY	3510-0039-01/03	Bombardier	CL-600-2D15 (Regional Jet Series 705)
Floor Panel Fitting	21759-52	21759-52EH	CRJ200, 700, & 900 AIRCRAFT	21759-52	Bombardier	CL-600-2D15 (Regional Jet Series 705)
Immersion Heater	200-0368-01	200-0368-01EH	COFFEE BREWER	1448, 1448-1, 1448-4	Bombardier	CL-600-2D24 (Regional Jet Series 900)
Heater Assembly	3575-1251-05	3575-1251-05EH	HEATER ASSEMBLY	3510-0039-01/03	Bombardier	CL-600-2D24 (Regional Jet Series 900)
Passenger Door Wheel Support Bearing	601R38371-9	601R38371-9EH	Support	CC670-38624-3	Bombardier	CL-600-2D24 (Regional Jet Series 900)
Floor Panel Fitting	21759-52	21759-52EH	CRJ200, 700, & 900 AIRCRAFT	21759-52	Bombardier	CL-600-2D24 (Regional Jet Series 900)
Enclosure	23088-1091	23088-1091EH	DC GENERATOR	23088 SERIES	Bombardier	DHC-7-100
Thermostatic Switch	31708-1480	31708-1480EH	DC GENERATOR	23088 SERIES	Bombardier	DHC-7-100
Bearing Shield	23088-1340	23088-1340EH	STARTER GENERATOR	23088 SERIES	Bombardier	DHC-7-100
Bearing Shield	23088-1342	23088-1342EH	STARTER GENERATOR	23088 SERIES	Bombardier	DHC-7-100
Enclosure	23088-1091	23088-1091EH	DC GENERATOR	23088 SERIES	Bombardier	DHC-7-101
Thermostatic Switch	31708-1480	31708-1480EH	DC GENERATOR	23088 SERIES	Bombardier	DHC-7-101
Bearing Shield	23088-1340	23088-1340EH	STARTER GENERATOR	23088 SERIES	Bombardier	DHC-7-101
Bearing Shield	23088-1342	23088-1342EH	STARTER GENERATOR	23088 SERIES	Bombardier	DHC-7-101
Enclosure	23088-1091	23088-1091EH	DC GENERATOR	23088 SERIES	Bombardier	DHC-7-102
Thermostatic Switch	31708-1480	31708-1480EH	DC GENERATOR	23088 SERIES	Bombardier	DHC-7-102
Bearing Shield	23088-1340	23088-1340EH	STARTER GENERATOR	23088 SERIES	Bombardier	DHC-7-102
Bearing Shield	23088-1342	23088-1342EH	STARTER GENERATOR	23088 SERIES	Bombardier	DHC-7-102
Enclosure	23088-1091	23088-1091EH	DC GENERATOR	23088 SERIES	Bombardier	DHC-7-103

Thermostatic Switch	31708-1480	31708-1480EH	DC GENERATOR	23088 SERIES	Bombardier	DHC-7-103
Bearing Shield	23088-1340	23088-1340EH	STARTER GENERATOR	23088 SERIES	Bombardier	DHC-7-103
Bearing Shield	23088-1342	23088-1342EH	STARTER GENERATOR	23088 SERIES	Bombardier	DHC-7-103
Bearing	03-6009-23	EH03-6009-23	STARTER GENERATOR	23088-008	Bombardier	DHC-8-100 Series
Bearing	03-6009-25	EH03-6009-25	STARTER GENERATOR	23088-008	Bombardier	DHC-8-100 Series
Bearing	400SG1052-13	EH400SG1052-13	STARTER GENERATOR	400SG MODEL LIST	Bombardier	DHC-8-100 series
Bearing	250SG1052-B	EH250SG1052-B	STARTER GENERATOR	300SG MODEL LIST	Bombardier	DHC-8-100 Series
Bearing	150SG1052-B	EH150SG1052-B	STARTER GENERATOR	200SG MODEL LIST	Bombardier	DHC-8-100 Series
Brush	30300-1413	EH30300-1413	STARTER GENERATOR	23085-Series (028, 029, 030, 031, 005)	Bombardier	DHC-8-100 Series
Brush	738466-6	EH738466-6	BRUSH BLOCK ASSEMBLY	782689-1 THRU -6	Bombardier	DHC-8-100 Series
Bearing	03-6009-18	EH03-6009-18	STARTER GENERATOR	23085-Series (028, 029, 030, 031, 005)	Bombardier	DHC-8-100 Series
Teflon Brush Block Pad	789285-1	EH789285-1	BRUSH BLOCK ASSEMBLY	782689-1 Thru -6	Bombardier	DHC-8-100 Series
Brush	R30300-1413	EHR30300-1413	STARTER GENERATOR	23085-Series (028, 029, 030, 031, 005)	Bombardier	DHC-8-100 Series
Brush	R23088-1321	EHR23088-1321	STARTER GENERATOR	23088-X	Bombardier	DHC-8-100 Series
Magnetic Speed Pick-Up	SP-1	EHSP-1	STARTER GENERATOR	23080-SERIES, 23081-SERIES, 23085-SERIES,23095-SERIES, 8260-121, 8160-121, 200SG-SERIES, 300SG SERIES, 400SG-SERIES	Bombardier	DHC-8-100 Series
Bearing	03-6009-18	EH03-6009-18	STARTER GENERATOR	23085-Series (028, 029, 030, 031, 005)	Bombardier	DHC-8-100 Series
Enclosure	23088-1091	23088-1091EH	DC GENERATOR	23088 SERIES	Bombardier	DHC-8-100 Series
Thermostatic Switch	31708-1480	31708-1480EH	DC GENERATOR	23088 SERIES	Bombardier	DHC-8-100 Series
Bearing	03-6009-23	EH03-6009-23	STARTER GENERATOR	23088-008	Bombardier	DHC-8-100 Series
Bearing	03-6009-23	EH03-6009-23	STARTER GENERATOR	23088-008	Bombardier	DHC-8-100 Series
Bearing	03-6009-23	EH03-6009-23	STARTER GENERATOR	23088-008	Bombardier	DHC-8-100 Series
Bearing	03-6009-23	EH03-6009-23	STARTER GENERATOR	23088-008	Bombardier	DHC-8-100 Series
Bearing Shield	23088-1340	23088-1340EH	STARTER GENERATOR	23088 SERIES	Bombardier	DHC-8-100 series
Bearing Shield	23088-1342	23088-1342EH	STARTER GENERATOR	23088 SERIES	Bombardier	DHC-8-100 series
Bearing	250SG1052	250SG1052EH	STARTER GENERATOR	250SG111Q, 250SG112Q, 250SG114Q, 250SG115Q, 250SG116Q, 250SG117Q, 250SG123Q, 300SGL111Q-1, 300SGL115Q, 300SGL116Q, 300SGL127Q-1, 300SGL127Q-3, 300SGL127Q-4, 300SGL145Q, 300SGL146Q	Bombardier	DHC-8-100 Series
Brushes	300SGL1009-5	300SGL1009-5EH	STARTER GENERATOR	300SGL111Q-1, 300SGL115Q, 300SGL118Q, 300SGL127Q-2, 300SGL129Q, 300SGL138Q-4, 300SGL146Q, 300SGL150Q, 300SGL162Q, 300SGL111Q-2, 300SGL116Q, 300SGL126Q, 300SGL127Q-3, 300SGL129Q-2, 300SGL138Q-5, 300SGL146Q-2, 300SGL153Q, 300SGL162Q-2, 300SGL114Q, 300SGL116Q-2, 300SGL127Q-1, 300SGL127Q-4, 300SGL138Q-2, 300SGL139Q, 300SGL146Q-3, 300SGL157Q, 300SGL162Q-3	Bombardier	DHC-8-100 series
Bearing	03-6009-23	EH03-6009-23	STARTER GENERATOR	23088-008	Bombardier	DHC-8-200 Series
Bearing	03-6009-25	EH03-6009-25	STARTER GENERATOR	23088-008	Bombardier	DHC-8-200 Series

Bearing	250SG1052-B	EH250SG1052-B	STARTER GENERATOR	300SG MODEL LIST	Bombardier	DHC-8-200 Series
Brush	30300-1413	EH30300-1413	STARTER GENERATOR	23085-Series (028, 029, 030, 031, 005)	Bombardier	DHC-8-200 Series
Bearing	03-6009-18	EH03-6009-18	STARTER GENERATOR	23085-Series (028, 029, 030, 031, 005)	Bombardier	DHC-8-200 Series
Teflon Brush Block Pad	789285-1	EH789285-1	BRUSH BLOCK ASSEMBLY	782689-1 Thru -6	Bombardier	DHC-8-200 Series
Brush	R30300-1413	EHR30300-1413	STARTER GENERATOR	23085-Series (028, 029, 030, 031, 005)	Bombardier	DHC-8-200 Series
Brush	R23088-1321	EHR23088-1321	STARTER GENERATOR	23088-X	Bombardier	DHC-8-200 Series
Magnetic Speed Pick-Up	SP-1	EHSP-1	STARTER GENERATOR	23080-SERIES, 23081-SERIES, 23085-SERIES,23095-SERIES, 8260-121, 8160-121, 200SG-SERIES, 300SG SERIES, 400SG-SERIES	Bombardier	DHC-8-200 Series
Bearing	03-6009-18	EH03-6009-18	STARTER GENERATOR	23085-Series (028, 029, 030, 031, 005)	Bombardier	DHC-8-200 Series
Enclosure	23088-1091	23088-1091EH	DC GENERATOR	23088 SERIES	Bombardier	DHC-8-200 Series
Thermostatic Switch	31708-1480	31708-1480EH	DC GENERATOR	23088 SERIES	Bombardier	DHC-8-200 Series
Bearing	03-6009-23	EH03-6009-23	STARTER GENERATOR	23088-008	Bombardier	DHC-8-200 Series
Bearing	03-6009-23	EH03-6009-23	STARTER GENERATOR	23088-008	Bombardier	DHC-8-200 Series
Bearing	03-6009-23	EH03-6009-23	STARTER GENERATOR	23088-008	Bombardier	DHC-8-200 Series
Bearing	03-6009-23	EH03-6009-23	STARTER GENERATOR	23088-008	Bombardier	DHC-8-200 Series
Bearing Shield	23088-1340	23088-1340EH	STARTER GENERATOR	23088 SERIES	Bombardier	DHC-8-200 series
Bearing Shield	23088-1342	23088-1342EH	STARTER GENERATOR	23088 SERIES	Bombardier	DHC-8-200 series
Brushes	300SGL1009-5	300SGL1009-5EH	STARTER GENERATOR	300SGL111Q-1, 300SGL115Q, 300SGL118Q, 300SGL127Q-2, 300SGL129Q, 300SGL138Q-4, 300SGL146Q, 300SGL150Q, 300SGL162Q, 300SGL111Q-2, 300SGL116Q, 300SGL126Q, 300SGL127Q-3, 300SGL129Q-2, 300SGL138Q-5, 300SGL146Q-2, 300SGL153Q, 300SGL162Q-2, 300SGL114Q, 300SGL116Q-2, 300SGL127Q-1, 300SGL127Q-4, 300SGL138Q-2, 300SGL139Q, 300SGL146Q-3, 300SGL157Q, 300SGL162Q-3	Bombardier	DHC-8-200 series
Bearing	03-6009-23	EH03-6009-23	STARTER GENERATOR	23088-008	Bombardier	DHC-8-300 Series
Bearing	03-6009-25	EH03-6009-25	STARTER GENERATOR	23088-008	Bombardier	DHC-8-300 Series
Bearing	250SG1052-B	EH250SG1052-B	STARTER GENERATOR	300SG MODEL LIST	Bombardier	DHC-8-300 Series
Bearing	150SG1052-B	EH150SG1052-B	STARTER GENERATOR	200SG MODEL LIST	Bombardier	DHC-8-300 Series
Brush	30300-1413	EH30300-1413	STARTER GENERATOR	23085-Series (028, 029, 030, 031, 005)	Bombardier	DHC-8-300 Series
Brush	738466-6	EH738466-6	BRUSH BLOCK ASSEMBLY	782689-1 THRU -6	Bombardier	DHC-8-300 Series
Bearing	03-6009-18	EH03-6009-18	STARTER GENERATOR	23085-Series (028, 029, 030, 031, 005)	Bombardier	DHC-8-300 Series
Teflon Brush Block Pad	789285-1	EH789285-1	BRUSH BLOCK ASSEMBLY	782689-1 Thru -6	Bombardier	DHC-8-300 Series
Brush	R30300-1413	EHR30300-1413	STARTER GENERATOR	23085-Series (028, 029, 030, 031, 005)	Bombardier	DHC-8-300 Series
Brush	R23088-1321	EHR23088-1321	STARTER GENERATOR	23088-X	Bombardier	DHC-8-300 Series
Magnetic Speed Pick-Up	SP-1	EHSP-1	STARTER GENERATOR	23080-SERIES, 23081-SERIES, 23085-SERIES,23095-SERIES, 8260-121, 8160-121, 200SG-SERIES, 300SG SERIES, 400SG-SERIES	Bombardier	DHC-8-300 Series
Bearing	03-6009-18	EH03-6009-18	STARTER GENERATOR	23085-Series (028, 029, 030, 031, 005)	Bombardier	DHC-8-300 Series
Enclosure	23088-1091	23088-1091EH	DC GENERATOR	23088 SERIES	Bombardier	DHC-8-300 Series

Thermostatic Switch	31708-1480	31708-1480EH	DC GENERATOR	23088 SERIES	Bombardier	DHC-8-300 Series
Bearing	03-6009-23	EH03-6009-23	STARTER GENERATOR	23088-008	Bombardier	DHC-8-300 Series
Bearing	03-6009-23	EH03-6009-23	STARTER GENERATOR	23088-008	Bombardier	DHC-8-300 Series
Bearing	03-6009-23	EH03-6009-23	STARTER GENERATOR	23088-008	Bombardier	DHC-8-300 Series
Bearing	03-6009-23	EH03-6009-23	STARTER GENERATOR	23088-008	Bombardier	DHC-8-300 Series
Bearing Shield	23088-1340	23088-1340EH	STARTER GENERATOR	23088 SERIES	Bombardier	DHC-8-300 series
Bearing Shield	23088-1342	23088-1342EH	STARTER GENERATOR	23088 SERIES	Bombardier	DHC-8-300 series
Bearing	250SG1052	250SG1052EH	STARTER GENERATOR	250SG111Q, 250SG112Q, 250SG114Q, 250SG115Q, 250SG116Q, 250SG117Q, 250SG123Q, 300SGL11Q-1, 300SGL115Q, 300SGL116Q, 300SGL127Q-1, 300SGL127Q-3, 300SGL127Q-4, 300SGL145Q, 300SGL146Q	Bombardier	DHC-8-300 Series
Brushes	300SGL1009-5	300SGL1009-5EH	STARTER GENERATOR	300SGL111Q-1, 300SGL115Q, 300SGL118Q, 300SGL127Q-2, 300SGL129Q, 300SGL138Q-4, 300SGL146Q, 300SGL150Q, 300SGL162Q, 300SGL111Q-2, 300SGL116Q, 300SGL126Q, 300SGL127Q-3, 300SGL129Q-2, 300SGL138Q-5, 300SGL146Q-2, 300SGL153Q, 300SGL162Q-2, 300SGL114Q, 300SGL116Q-2, 300SGL127Q-1, 300SGL127Q-4, 300SGL138Q-2, 300SGL139Q, 300SGL146Q-3, 300SGL157Q, 300SGL162Q-3	Bombardier	DHC-8-300 series
Bearing	03-6009-23	EH03-6009-23	STARTER GENERATOR	23088-008	Bombardier	DHC-8-400 Series
Bearing	250SG1052-B	EH250SG1052-B	STARTER GENERATOR	300SG MODEL LIST	Bombardier	DHC-8-400 Series
Bearing	150SG1052-B	EH150SG1052-B	STARTER GENERATOR	200SG MODEL LIST	Bombardier	DHC-8-400 Series
Brush	30300-1413	EH30300-1413	STARTER GENERATOR	23085-Series (028, 029, 030, 031, 005)	Bombardier	DHC-8-400 Series
Brush	738466-6	EH738466-6	BRUSH BLOCK ASSEMBLY	782689-1 THRU -6	Bombardier	DHC-8-400 Series
Bearing	03-6009-18	EH03-6009-18	STARTER GENERATOR	23085-Series (028, 029, 030, 031, 005)	Bombardier	DHC-8-400 Series
Teflon Brush Block Pad	789285-1	EH789285-1	BRUSH BLOCK ASSEMBLY	782689-1 Thru -6	Bombardier	DHC-8-400 Series
Brush	R30300-1413	EHR30300-1413	STARTER GENERATOR	23085-Series (028, 029, 030, 031, 005)	Bombardier	DHC-8-400 Series
Brush	R23088-1321	EHR23088-1321	STARTER GENERATOR	23088-X	Bombardier	DHC-8-400 Series
Magnetic Speed Pick-Up	SP-1	EHSP-1	STARTER GENERATOR	23080-SERIES, 23081-SERIES, 23085-SERIES,23095-SERIES, 8260-121, 8160-121, 200SG-SERIES, 300SG SERIES, 400SG-SERIES	Bombardier	DHC-8-400 Series
Magnetic Speed Pick-Up	SP-1	EHSP-1	STARTER GENERATOR	23080-SERIES, 23081-SERIES, 23085-SERIES,23095-SERIES, 8260-121, 8160-121, 200SG-SERIES, 300SG SERIES, 400SG-SERIES	Bombardier	DHC-8-400 Series
Bearing	03-6009-18	EH03-6009-18	STARTER GENERATOR	23085-Series (028, 029, 030, 031, 005)	Bombardier	DHC-8-400 Series
Bearing	03-6009-23	EH03-6009-23	STARTER GENERATOR	23088-008	Bombardier	DHC-8-400 Series
Bearing	03-6009-23	EH03-6009-23	STARTER GENERATOR	23088-008	Bombardier	DHC-8-400 Series
Bearing	03-6009-23	EH03-6009-23	STARTER GENERATOR	23088-008	Bombardier	DHC-8-400 Series

Drive Shaft Assembly	400SG1103-12	400SG1103-12EH	STARTER GENERATOR	400SG115Q, 400SG123Q, 400SG142Q, 400SG163Q, 400SG168Q, 400SG157Q, 400SG166Q, 400SG147Q	Bombardier	DHC-8-400 series
Brushes	300SGL1009-5	300SGL1009-5EH	STARTER GENERATOR	300SGL111Q-1, 300SGL115Q, 300SGL118Q, 300SGL127Q-2, 300SGL129Q, 300SGL138Q-4, 300SGL146Q, 300SGL150Q, 300SGL162Q, 300SGL111Q-2, 300SGL116Q, 300SGL126Q, 300SGL127Q-3, 300SGL129Q-2, 300SGL138Q-5, 300SGL146Q-2, 300SGL153Q, 300SGL162Q-2, 300SGL114Q, 300SGL116Q-2, 300SGL127Q-1, 300SGL127Q-4, 300SGL138Q-2, 300SGL139Q, 300SGL146Q-3, 300SGL157Q, 300SGL162Q-3	Bombardier	DHC-8-400 series
Brushes	400SG1009-7	400SG1009-7EH	STARTER GENERATOR	1152106-2 SERIES 1, 1152106-3 SERIES 1, 1152106-2 SERIES 2, 1152106-3 SERIES 2	Bombardier	DHC-8-400 series