



# Eurocopter Application List

P: 705-742-9725

[www.kadexaero.com](http://www.kadexaero.com)

Contact:



Descrtiption	OEM PN	Seginus PN	NHA Description	NHA PN	Aircraft	Aircraft Model Number
Bearing	150SG1052-B	EH150SG1052-B	STARTER GENERATOR	200SG MODEL LIST	Eurocopter France	AS350B
Brush	23033-1141	EH23033-1141	STARTER GENERATOR	23032-020, 23032-022	Eurocopter France	AS350B
Bearing	410964	410964EH	STARTER GENERATOR	524-060* (61, 62)	Eurocopter France	AS350B
Bearing	410997	410997EH	STARTER GENERATOR	524-060* (61, 62)	Eurocopter France	AS350B
Bearing	150SG1052-B	EH150SG1052-B	STARTER GENERATOR	200SG MODEL LIST	Eurocopter France	AS350B1
Bearing	410964	410964EH	STARTER GENERATOR	524-060* (61, 62)	Eurocopter France	AS350B1
Bearing	410997	410997EH	STARTER GENERATOR	524-060* (61, 62)	Eurocopter France	AS350B1
Bearing	B320050L	EHB320050L	STARTER GENERATOR	8260-121, 8260-123	Eurocopter France	AS350B2
Bearing	150SG1052-B	EH150SG1052-B	STARTER GENERATOR	200SG MODEL LIST	Eurocopter France	AS350B2
Bearing	410964	410964EH	STARTER GENERATOR	524-060* (61, 62)	Eurocopter France	AS350B2
Bearing	410997	410997EH	STARTER GENERATOR	524-060* (61, 62)	Eurocopter France	AS350B2
Bearing	B320050L	EHB320050L	STARTER GENERATOR	8260-121, 8260-123	Eurocopter France	AS350B3
Bearing	150SG1052-B	EH150SG1052-B	STARTER GENERATOR	200SG MODEL LIST	Eurocopter France	AS350B3
Bearing	410964	410964EH	STARTER GENERATOR	524-060* (61, 62)	Eurocopter France	AS350B3
Bearing	410997	410997EH	STARTER GENERATOR	524-060* (61, 62)	Eurocopter France	AS350B3
Bearing	150SG1052-B	EH150SG1052-B	STARTER GENERATOR	200SG MODEL LIST	Eurocopter France	AS350B4
Bearing	B320050L	EHB320050L	STARTER GENERATOR	8260-121, 8260-123	Eurocopter France	AS350BA
Bearing	150SG1052-B	EH150SG1052-B	STARTER GENERATOR	200SG MODEL LIST	Eurocopter France	AS350BA
Brush	23033-1141	EH23033-1141	STARTER GENERATOR	23032-020, 23032-022	Eurocopter France	AS350BA
Bearing	410964	410964EH	STARTER GENERATOR	524-060* (61, 62)	Eurocopter France	AS350BA
Bearing	410997	410997EH	STARTER GENERATOR	524-060* (61, 62)	Eurocopter France	AS350BA
Bearing	03-6009-23	EH03-6009-23	STARTER GENERATOR	23088-008	Eurocopter France	AS350C
Bearing	150SG1052-B	EH150SG1052-B	STARTER GENERATOR	200SG MODEL LIST	Eurocopter France	AS350C
Brush	23033-1141	EH23033-1141	STARTER GENERATOR	23032-020, 23032-022	Eurocopter France	AS350C
Bearing	410964	410964EH	STARTER GENERATOR	524-060* (61, 62)	Eurocopter France	AS350C
Bearing	410997	410997EH	STARTER GENERATOR	524-060* (61, 62)	Eurocopter France	AS350C
Bearing	B320050L	EHB320050L	STARTER GENERATOR	8260-121, 8260-123	Eurocopter France	AS350D
Bearing	03-6009-23	EH03-6009-23	STARTER GENERATOR	23088-008	Eurocopter France	AS350D
Bearing	150SG1052-B	EH150SG1052-B	STARTER GENERATOR	200SG MODEL LIST	Eurocopter France	AS350D
Brush	23033-1141	EH23033-1141	STARTER GENERATOR	23032-020, 23032-022	Eurocopter France	AS350D
Bearing	410964	410964EH	STARTER GENERATOR	524-060* (61, 62)	Eurocopter France	AS350D
Bearing	410997	410997EH	STARTER GENERATOR	524-060* (61, 62)	Eurocopter France	AS350D
Bearing	03-6009-23	EH03-6009-23	STARTER GENERATOR	23088-008	Eurocopter France	AS350D1

Bearing	150SG1052-B	EH150SG1052-B	STARTER GENERATOR	200SG MODEL LIST	Eurocopter France	AS350D1
Bearing	410964	410964EH	STARTER GENERATOR	524-060* (61, 62)	Eurocopter France	AS350D1
Bearing	410997	410997EH	STARTER GENERATOR	524-060* (61, 62)	Eurocopter France	AS350D1
Bearing	03-6009-23	EH03-6009-23	STARTER GENERATOR	23088-008	Eurocopter France	AS355E
Bearing	410964	410964EH	STARTER GENERATOR	524-060* (61, 62)	Eurocopter France	AS355E
Bearing	410997	410997EH	STARTER GENERATOR	524-060* (61, 62)	Eurocopter France	AS355E
Bearing	03-6009-23	EH03-6009-23	STARTER GENERATOR	23088-008	Eurocopter France	AS355F
Bearing	150SG1052-B	EH150SG1052-B	STARTER GENERATOR	200SG MODEL LIST	Eurocopter France	AS355F
Bearing	410964	410964EH	STARTER GENERATOR	524-060* (61, 62)	Eurocopter France	AS355F
Bearing	410997	410997EH	STARTER GENERATOR	524-060* (61, 62)	Eurocopter France	AS355F
Bearing	03-6009-23	EH03-6009-23	STARTER GENERATOR	23088-008	Eurocopter France	AS355F1
Bearing	150SG1052-B	EH150SG1052-B	STARTER GENERATOR	200SG MODEL LIST	Eurocopter France	AS355F1
Bearing	410964	410964EH	STARTER GENERATOR	524-060* (61, 62)	Eurocopter France	AS355F1
Bearing	410997	410997EH	STARTER GENERATOR	524-060* (61, 62)	Eurocopter France	AS355F1
Bearing	03-6009-23	EH03-6009-23	STARTER GENERATOR	23088-008	Eurocopter France	AS355F2
Bearing	150SG1052-B	EH150SG1052-B	STARTER GENERATOR	200SG MODEL LIST	Eurocopter France	AS355F2
Brush	23033-1141	EH23033-1141	STARTER GENERATOR	23032-020, 23032-022	Eurocopter France	AS355F2
Bearing	410964	410964EH	STARTER GENERATOR	524-060* (61, 62)	Eurocopter France	AS355F2
Bearing	410997	410997EH	STARTER GENERATOR	524-060* (61, 62)	Eurocopter France	AS355F2
Bearing	B320050L	EHB320050L	STARTER GENERATOR	8260-121, 8260-123	Eurocopter France	AS355N
Bearing	150SG1052-B	EH150SG1052-B	STARTER GENERATOR	200SG MODEL LIST	Eurocopter France	AS355N
Bearing	410964	410964EH	STARTER GENERATOR	524-060* (61, 62)	Eurocopter France	AS355N
Bearing	410997	410997EH	STARTER GENERATOR	524-060* (61, 62)	Eurocopter France	AS355N
Bearing	410964	410964EH	STARTER GENERATOR	524-060* (61, 62)	Eurocopter France	AS355NP
Bearing	410997	410997EH	STARTER GENERATOR	524-060* (61, 62)	Eurocopter France	AS355NP
Bearing	150SG1052-B	EH150SG1052-B	STARTER GENERATOR	200SG MODEL LIST	Eurocopter France	AS355P
Bearing	03-6009-23	EH03-6009-23	STARTER GENERATOR	23088-008	Eurocopter Deutschland GmbH	BO-105A
Bearing	150SG1052-B	EH150SG1052-B	STARTER GENERATOR	200SG MODEL LIST	Eurocopter Deutschland GmbH	BO-105A
Bearing	03-6009-23	EH03-6009-23	STARTER GENERATOR	23088-008	Eurocopter Deutschland GmbH	BO-105C
Bearing	150SG1052-B	EH150SG1052-B	STARTER GENERATOR	200SG MODEL LIST	Eurocopter Deutschland GmbH	BO-105C
Bearing	03-6009-23	EH03-6009-23	STARTER GENERATOR	23088-008	Eurocopter Deutschland GmbH	BO-105S
Bearing	150SG1052-B	EH150SG1052-B	STARTER GENERATOR	200SG MODEL LIST	Eurocopter Deutschland GmbH	BO-105S
Bearing	03-6009-23	EH03-6009-23	STARTER GENERATOR	23088-008	Eurocopter Deutschland GmbH	BO-105S A-1

Bearing	150SG1052-B	EH150SG1052-B	STARTER GENERATOR	200SG MODEL LIST	Eurocopter Deutschland GmbH	BO-105S A-1
Bearing	03-6009-23	EH03-6009-23	STARTER GENERATOR	23088-008	Eurocopter Deutschland GmbH	BO-105S A-3
Bearing	150SG1052-B	EH150SG1052-B	STARTER GENERATOR	200SG MODEL LIST	Eurocopter Deutschland GmbH	BO-105S A-3
Bearing	150SG1052-B	EH150SG1052-B	STARTER GENERATOR	200SG MODEL LIST	Eurocopter France	EC120B
Bearing	03-6009-23	EH03-6009-23	STARTER GENERATOR	23088-008	Eurocopter Deutschland GmbH	EC135
Brush	23033-1141	EH23033-1141	STARTER GENERATOR	23032-020, 23032-022	Eurocopter Deutschland GmbH	MBB-BK 117 A-1
Brush	23033-1141	EH23033-1141	STARTER GENERATOR	23032-020, 23032-022	Eurocopter Deutschland GmbH	MBB-BK 117 A-3
Brush	23033-1141	EH23033-1141	STARTER GENERATOR	23032-020, 23032-022	Eurocopter Deutschland GmbH	MBB-BK 117 A-4
Brush	23033-1141	EH23033-1141	STARTER GENERATOR	23032-020, 23032-022	Eurocopter Deutschland GmbH	MBB-BK 117 B-1
Bearing	03-6009-18	EH03-6009-18	STARTER GENERATOR	23085-Series (028, 029, 030, 031, 005)	Eurocopter Deutschland GmbH	MBB-BK 117 B-1
Bearing	03-6009-18	EH03-6009-18	STARTER GENERATOR	23085-Series (028, 029, 030, 031, 005)	Eurocopter Deutschland GmbH	MBB-BK 117 B-2
Bearing	03-6009-18	EH03-6009-18	STARTER GENERATOR	23085-Series (028, 029, 030, 031, 005)	Eurocopter Deutschland GmbH	MBB-BK117B-1